

BLACKMER GEAR PUMP


INSTALLATION OPERATION AND MAINTENANCE INSTRUCTIONS
MODELS: G-SERIES

960701

INSTRUCTIONS NO. 1902-a00

Section	1902
Effective	July 2026
Replaces	June 2025

G Series Sealed Internal Gear Pumps



Where Innovation Flows

Blackmer

1902-a00

Always read the most current version of this manual before performing any work on or around this pump. The most current version of this manual is freely available on the web at www.blackmer.com

Blackmer pumps are specifically configured for your unique application conditions. Those application conditions and the details of the pump configuration were documented during the ordering process. Keep that information available in a safe place, as it may be needed when troubleshooting pump problems or when ordering spare parts or repairs.

Blackmer Gear Pumps are covered by one or more of the following patents: U.S. Patent Nos. 7549205, 7137793, 7183683, 8,608,465B2 Australian Patent No. AU2005233534B2; Korean Patent No. 10-2006-7023162; Mexican Patent No. PA/2006/011436, Russian Patent No. 2006138540(041952); China Patent No. ZL 201280031563.6; and other patents pending.



About EnviroGear®

The information contained in this manual applies to both Blackmer® and EnviroGear G Series Internal Gear Pump models. For more information visit the psgdover.com/blackmer website.

Table of Contents

SECTION 1	CAUTIONS—READ FIRST!	4
SECTION 2	PUMP DESIGNATION SYSTEM	5
SECTION 3	HOW IT WORKS—INTERNAL GEAR TECHNOLOGY	9
SECTION 4	SUGGESTED INSTALLATION & OPERATION	10
SECTION 5	MAINTENANCE	15
SECTION 6	DISASSEMBLY	17
SECTION 7	REASSEMBLY	19
SECTION 8	TROUBLESHOOTING	24
SECTION 9	WARRANTY	26

Cautions—Read First!

-  **CAUTION:** Only personnel who are familiar with the operation and repair of mechanical products should perform the necessary maintenance. You must familiarize yourself with the entire contents of this manual prior to operating and/or performing any maintenance.
-  **CAUTION:** When selecting a G Series pump for an application, you must first ensure that the pump components are compatible with the process media.
-  **CAUTION:** Prior to startup, review and understand end-clearance adjustments. Following these guidelines will ensure proper end-clearance adjustment avoiding interference between the gears and head. Interference may cause heat generation and premature wear.
-  **CAUTION:** Do not operate this pump in excess of its rated capacity, pressure, speed and temperature.
-  **CAUTION:** Before any maintenance and repair is attempted, disconnect the drive.
-  **CAUTION:** Before any maintenance or repair is attempted, bleed all pressure from the pump through the suction or discharge lines.
-  **CAUTION:** Do not remove any pressure-containing components during pump operation.
-  **CAUTION:** All G Series pumps contain residual hydraulic oil from the factory production test. Hy-par-FG 15 food-grade oil is the standard production test fluid, but any certified performance testing may be done on a non-food grade oil, such as Unilube 32 (ISO 32) or Unilube 100 (ISO 100). Determine if this is compatible with the fluid you are pumping. If the fluid is incompatible, then the pump must be fully flushed prior to use.
-  **CAUTION:** When pumping fluids at elevated temperatures, care should be taken to gradually increase temperature. Rapid temperature increase can damage internal components.
-  **CAUTION:** Ensure that the pump has cooled to a safe temperature, especially pumps equipped with a jacket, before any maintenance or repair is attempted.
-  **CAUTION:** When pumping fluids at elevated temperatures the piping may expand, resulting in excessive stress on the pump. This can cause pump failure. Care must be taken when considering pipe design to avoid damage from thermal expansion.
-  **CAUTION:** Do not run the pump dry. This can cause damage to internal components and generate heat, creating a hazardous condition for volatile fluids.
-  **CAUTION:** Prevention of static sparking – If static sparking occurs, fire or explosion could result. Pump, valves and containers must be grounded to a proper grounding point when handling flammable fluids and whenever discharge of static electricity is a hazard.
-  **CAUTION:** The packing in a packed pump is designed to leak. Therefore, when pumping hazardous liquids, a mechanical seal is recommended to minimize any potential source of leakage that could result in a hazardous condition.
-  **CAUTION:** Do not adjust packing while pump is in operation.
-  **CAUTION:** All inlet and discharge plumbing should be clean and free from foreign material prior to startup of pump.
-  **CAUTION:** Keep hands and fingers away from any pump opening while the pump is connected to the drive.
-  **CAUTION:** When connecting to an electric motor, follow all safety recommendations provided by the motor manufacturer.
-  **WARNING:** In any positive-displacement pump system, a reliable pressure-protection device must be used in the discharge piping to avoid a dangerous pressure increase, which could cause the pump or any component in the discharge piping to burst and can lead to serious injury. A pump-mounted integral relief valve is not intended to be used in this manner.
-  **WARNING:** During operation the pump surface temperature can exceed 140°F (60°C). Allow for proper cooling before any handling.
-  **CAUTION:** Never remove safety guards from shafts, couplings, V-belts or pulleys during operation. Doing so could result in injury.
-  **CAUTION:** When pumping high-temperature fluids, avoid contact with the pump. Serious injury could occur.
-  **CAUTION:** Do not wear loose or dangling clothing or jewelry near the equipment. These items could become caught in the equipment and cause injury.
-  **CAUTION:** Before any maintenance or repair is attempted, ensure that the pump has been thoroughly flushed of any hazardous fluids. Review the Material Safety Data Sheet (MSDS) applicable to the fluid for proper handling.

Designation System

EXAMPLE:

G1-133SNB/4ALT/C9TCN/N/NNNN/000

G	CONFIG	MODEL	EXTERNALS	INTERNALS	CLEARANCE	PORTS	ORIENTATION	BUSHINGS	SEAL TYPE / MATERIAL	SEAL FACES	RELIEF VALVE	JACKET OPTIONS	SPECIALTY CODE
	1	2	C	C	A	1.5A	RT	C	1B	CANR	N = NO RELIEF VALVE	XXXX	000
	2	4	S	D	B	1.5N	LT	B	1V	CASC	05	B	
	3	24	W	N	C	2A	RB	T	9T	CACR	06	C	
		32		S	D	2N	LB	I	PG	SCSC	07	H	
		55		W	E	2.5A	RL		PH	NAPA	08	V	
		69			F	3A	LR		3T	NPNS	09		
		82				4A			CV	SCAE	13		
		133				4E			40V	SCCE	15		
		222				4G			NP	SCVE	16		
						6A			8V	SCVG	20		
						6E				SCVV			
						6G				CATU			
										TUTU			
										SCTU			

MATERIAL CODES

CONFIGURATION

- 1 = Standard
2 = Jacketed
3 = Behind the Rotor Seal

MODELS

- 2 = 2 in³/rev
4 = 4 in³/rev
24 = 24 in³/rev
32 = 32 in³/rev
55 = 55 in³/rev
69 = 69 in³/rev
82 = 82 in³/rev
133 = 133 in³/rev
222 = 222 in³/rev

MATERIAL (EXTERNAL)

- C = CARBON STEEL
S = STAINLESS STEEL
W = CAST IRON

MATERIAL (INTERNAL)

- C = STEEL
D = DUCTILE IRON
N = NITRONIC 60
S = STAINLESS STEEL
W = CAST IRON

CLEARANCES (G1-2/4): IRON/STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [<160 cSt, 108-149°C (226-300°F)]
C = [<160 cSt, 150-232°C (301-450°F)]
D = [1,600-16,000 cSt, 233-343°C (451-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-2/4): STAINLESS STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [<160 cSt, 108-149°C (226-300°F)]
C = [1,600-16,000 cSt, 150-232°C (301-450°F)]
D = [1,600-16,000 cSt, 233-343°C (451-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-24/32): IRON/STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [<160 cSt, 108-149°C (226-300°F)]
C = [1,600-16,000 cSt, 150-232°C (301-450°F)]
D = [1,600-16,000 cSt, 233-343°C (451-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-24/32): IRON ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [<160 cSt, 108-149°C (226-300°F)]
C = [1,600-16,000 cSt, 150-232°C (301-450°F)]
D = [1,600-16,000 cSt, 233-343°C (451-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-24/32): STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [<160 cSt, 108-149°C (226-300°F)]
C = [1,600-16,000 cSt, 150-232°C (301-450°F)]
D = [1,600-16,000 cSt, 233-343°C (451-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-24/32): STAINLESS STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [<160 cSt, 108-149°C (226-300°F)]
C = [1,600-16,000 cSt, 150-232°C (301-450°F)]
D = [1,600-16,000 cSt, 233-343°C (451-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-55/69 & G2-55/69): IRON ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [<160 cSt, 108-149°C (226-300°F)]
C = [1,600-16,000 cSt, 150-232°C (301-450°F)]
D = [1,600-16,000 cSt, 233-343°C (451-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-55/69 & G2-55/69): STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [160-1,600 cSt, 108-232°C (226-450°F)]
C = [1,600-16,000 cSt, 233-343°C (451-650°F)]
D = [1,600-16,000 cSt, 302-343°C (576-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-55/69): STAINLESS STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [1,600-16,000 cSt, 108-177°C (226-350°F)]
C = [1,600-16,000 cSt, 177-260°C (351-500°F)]
D = [16,000-431,000 cSt, 177-260°C (351-500°F)]

CLEARANCES (G1-82 & G2-82): IRON ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [160-1,600 cSt, 108-232°C (226-450°F)]
C = [1,600-16,000 cSt, 233-343°C (451-650°F)]
D = [1,600-16,000 cSt, 302-343°C (576-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-82 & G2-82): STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [160-1,600 cSt, 108-232°C (226-450°F)]
C = [1,600-16,000 cSt, 233-343°C (451-650°F)]
D = [1,600-16,000 cSt, 302-343°C (576-650°F)]
E = [16,000-431,000 cSt, 302-343°C (576-650°F)]

CLEARANCES (G1-82):

STAINLESS STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [160-1,600 cSt, 108-163°C (226-325°F)]
C = [1,600-16,000 cSt, 163-260°C (326-500°F)]
D = [16,000-431,000 cSt, 163-260°C (326-500°F)]

CLEARANCES (G1-133/222 & G2-133/222): IRON ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [160-1,600 cSt, 108-232°C (226-450°F)]
C = [1,600-16,000 cSt, 233-343°C (451-650°F)]
D = [16,000-431,000 cSt, 233-343°C (451-650°F)]

CLEARANCES (G1-133/222): STEEL ROTOR

- A = [<160 cSt, <107°C (<225°F)]
B = [160-1,600 cSt, 108-232°C (226-450°F)]
C = [1,600-16,000 cSt, 233-343°C (451-650°F)]
D = [16,000-431,000 cSt, 233-343°C (451-650°F)]

CLEARANCES (G1-133/222): STAINLESS STEEL ROTOR

- A = [<1,600 cSt, <135°C (<275°F)]
B = [1,600-16,000 cSt, 136-260°C (276-500°F)]
C = [16,000-431,000 cSt, 136-260°C (276-500°F)]

PORTS

- 1.5A = 1.5 in ANSI
1.5N = 1.5 in NPT
2A = 2 in ANSI
2N = 2 in NPT
2.5A = 2.5 in ANSI
3A = 3 in ANSI
4A, 4E, 4G = 4 in ANSI, 150#, 300#
6A, 6E, 6G = 6 in ANSI, 150#, 300#

ORIENTATION (when looking at the shaft)

- RT = Right Port, Top Port
LT = Left Port, Top Port
RB = Right Port, Bottom Port
LB = Left Port, Bottom Port
RL = Right Port, Left Port
LR = Left Port, Right Port

BUSHING**

- C = Carbon-graphite bushings
B = Bronze bushings
T = Tungsten-carbide bushings
I = Hardened Cast Iron

**B-Seal bracket bushing always Bronze

SEAL TYPE/MATERIAL

- 1B = Type 1 Mechanical Seal (Buna-N)
1V = Type 1 Mechanical Seal (FKM)
8V = Type 8 Mechanical Seal (FKM)
9T = Type 9 Mechanical Seal (PTFE)
PG = Packing (PTFE-GRAPHITE) (<500°F)
PH = High Temperature Graphite Packing (<650°F)
3T = Triple Lip Seal
CV = Single Cartridge Seal (FKM)
40V = 40X3 Cartridge Seal (FKM)
NP = NO PACKING

SEAL FACES

- CANR = CARBON - NI-RESIST
CASC = CARBON - SILICON CARBIDE
CACR = CARBON - CERAMIC
CSUP = Customer Supplied
SCSC = SILICON CARBIDE - SILICON CARBIDE
NAPA = NOT APPLICABLE (PACKING)
NPNS = NO PACKING/NO SEAL
SCAE = SILICONE CARBIDE/ TFE/P ELASTOMERS
SCCE = SILICONE CARBIDE/ FFKM ELASTOMERS
SCVE = SILICONE CARBIDE/ VFKM ELASTOMERS
SCVG = SILICONE CARBIDE/ FKM ELASTOMERS, FDA GREASED
SCVV = SILICONE CARBIDE/ FKM ELASTOMERS, VACUUM



**RELIEF VALVE (G1-2/4):
CAST IRON /CARBON STEEL**

N = NO RELIEF VALVE
07 = 2.1 to 5.2 bar (30 to 75 psi)
12 = 5.2 to 8.6 bar (76 to 125 psi)
20 = 8.7 to 13.8 bar (126 to 200 psi)

RELIEF VALVE (G1-2/4): STAINLESS STEEL

N = NO RELIEF VALVE
07 = 2.1 to 5.2 bar (30 to 75 psi)
12 = 5.2 to 8.6 bar (76 to 125 psi)
15 = 8.7 TO 10.34 BAR (126 TO 150 psi)

**RELIEF VALVE (G1-24/32): CAST
IRON/CARBON STEEL**

N = NO RELIEF VALVE
05 = 1.0 to 3.5 bar (15 to 50 psi)
08 = 3.5 to 5.5 bar (51 to 80 psi)
15 = 5.6 to 10.3 bar (81 to 150 psi)
20 = 10.4 to 13.8 bar (151 to 200 psi)

RELIEF VALVE (G1-24/32): STAINLESS STEEL

N = NO RELIEF VALVE
05 = 1.0 to 3.5 bar (15 to 50 psi)
08 = 3.5 to 5.5 bar (51 to 80 psi)
15 = 5.6 to 10.3 bar (81 to 150 psi)

**RELIEF VALVE (G1-55/69/82 & G2-55/69/82):
CAST IRON**

N = NO RELIEF VALVE
06 = 1.4 to 4.1 bar (20 to 60 psi)
09 = 4.2 to 6.2 bar (61 to 90 psi)
16 = 6.3 to 11.1 bar (91 to 160 psi)
20 = 11.1 to 13.8 bar (161 to 200 psi)

RELIEF VALVE (G1-55/69/82): CARBON STEEL

N = NO RELIEF VALVE
06 = 1.4 to 4.1 bar (20 to 60 psi)
09 = 4.2 to 6.2 bar (61 to 90 psi)
16 = 6.3 to 11.1 bar (91 to 160 psi)
20 = 11.1 to 13.8 bar (161 to 200 psi)

**RELIEF VALVE (G1-55/69/82):
STAINLESS STEEL**

N = NO RELIEF VALVE
06 = 1.4 to 4.1 bar (20 to 60 psi)
09 = 4.2 to 6.2 bar (61 to 90 psi)
15 = 6.3 to 10.3 bar (91 to 150 psi)

**RELIEF VALVE (G1-133/222 & G2-133/222)
CAST IRON**

N = NO RELIEF VALVE
05 = 1.4 to 3.5 bar (20 to 50 psi)
08 = 3.5 to 5.5 bar (51 to 80 psi)
13 = 5.6 to 9.0 bar (81 to 130 psi)
20 = 9.0 TO 13.8 BAR (131 TO 200 PSI)

**RELIEF VALVE (G1-133/222)
STAINLESS STEEL**

N = NO RELIEF VALVE
05 = 1.4 to 3.5 bar (20 to 50 psi)
08 = 3.5 to 5.5 bar (51 to 80 psi)
13 = 5.6 to 9.0 bar (81 to 130 psi)
15 = 9.0 to 10.3 bar (131 to 150 psi)

CATU = CARBON - TUNGSTEN
TUTU = TUNGSTEN - TUNGSTEN
SCTU = SILICON CARBIDE – TUNGSTEN
JACKETED OPTIONS
NNNN = NO JACKETING
B = Bracket
C = Case
H = Head
V = Valve

EXAMPLE:

G1-55WWA/2NRT/CPGNA/20/NNNN/000_CXXXX_BSDCSXXX_GYYYYRZZ_MXXXZHPYYYY_ZZZV XXHz_AAA/B/WEG

_C	CERT				BASEPLATE											
	CERTIFIED HYDRO TEST	MATERIAL CERT	PMI CERT	PERFORMANCE TESTS	BASEPLATE SELECTED	BASEPLATE LENGTH REF	GEAR REDUCER AND RATIO	GEARBOX FRAME REF	MOTOR FRAME SIZE	MOTOR HP	MOTOR SPEED (RPM)	MOTOR VOLTAGE	MOTOR FREQ. (HZ)	MOTOR ENCLOSURE RATING	INVERTER DUTY	MOTOR MFG CODE
	X	X	X	X	BSDCS	XXX	GYYYY	RZZ	MXXX	ZHP	YYYY	ZZZ	XX	BLANK	Y	XXX
	N	A	N	P										EXP	N	
	W	B		N										TEFC	BLANK	
		C		W												
		D														

CERT CODES

C = DENOTES CERTIFICATION(S) SELECTED

CERTIFIED HYDRO TEST (WITNESS / NON-WITNESS)

X = Not Required
N = Certified Hydrostat Non-Witness
W = Certified Hydrostat Witness

MATERIAL CERTIFICATION (NOT REQUIRED / 3.1 MAT'L CERTS FOR WETTED COMPONENTS)

X = Not Required
A = 3.1 Material Certs for Wetted Components
B = 3.1 Material Certs (Pressure Containing) w/Photo – MCM
C = 2.2 Material Report (Pressure Containing) - MR
D = 2.2 Material Report (Pressure Containing) w/Photo - MPT

PMI CERTIFICATION (NOT REQUIRED / WETTED COMPONENTS NON-WITNESS / WETTED COMPONENTS WITNESS)

X = Not Required
N = Non-Witness

PERFORMANCE TESTS

X = Not Required
P = Production Test Report (PTR)
N = Certified Performance Test (Non-Witness)
W = Certified Performance Test (Witness)

BASEPLATE CODES

BSDCS = DESIGNATES BASEPLATE SELECTED
XXX = BASEPLATE LENGTH REFERENCE
GYYYY = GEAR REDUCER SELECTED AND RATIO
RZZ = GEARBOX FRAME REFERENCE
MXXX = MOTOR FRAME SIZE
ZHP = MOTOR HORSEPOWER

YYYY_ZZZVXXHZ

YYYY = Motor Speed in RPM
ZZZ = Motor Voltage
XX = Motor frequency in Hz

MOTOR ENCLOSURE RATING

Blank = No Rating
EXP = Explosion Proof
TEFC = Totally Enclosed Fan Cooled

B – INVERTER DUTY

Y = Yes
N = No
Blank = Not specified

XXX – MOTOR MANUFACTURER CODE

PUMP NOMINAL RATINGS

	Nominal Pump Rating		Max. Discharge Pressure	Max. Temperature	Nominal Pump Rating		Max. Discharge Pressure	Max. Temperature	Nominal Pump Rating		Max. Discharge Pressure	Max. Temperature
	CAST IRON				CARBON STEEL				STAINLESS STEEL			
Model	RPM	GPM (m3/h)	PSIG (bar)	Fahrenheit (Celsius)	RPM	GPM (m3/h)	PSIG (bar)	Fahrenheit (Celsius)	RPM	GPM (m3/h)	PSIG (bar)	Fahrenheit (Celsius)
G1-2	1,750	15 (3.4)	200 (13.8) >20 cSt	650° (343°)	1,750	15 (3.4)	200 (13.8) >20 cSt	650° (343°)	1,150	10 (2.3)	150 (10.3) >550 cSt	500° (260°)
G3-2	1,750	15 (3.4)	200 (13.8) >20 cSt	400° (204°)	-	-	-	-	-	-	-	-
G1-4	1,750	30 (6.8)	200 (13.8) >20 cSt	650° (343°)	1,750	30 (6.8)	200 (13.8) >20 cSt	650° (343°)	1,150	20 (4.5)	150 (10.3) >550 cSt	500° (260°)
G3-4	1,750	30 (6.8)	200 (13.8) >20 cSt	400° (204°)	-	-	-	-	-	-	-	-
G1-24	780	75 (17.0)	200 (13.8) >20 cSt	650° (343°)	780	75 (17.0)	200 (13.8) >20 cSt	650° (343°)	520	50 (11.4)	150 (10.3) >550 cSt	500° (260°)
G3-24	780	75 (17.0)	200 (13.8) >20 cSt	400° (204°)	-	-	-	-	-	-	-	-
G1-32	780	100 (22.7)	200 (13.8) >20 cSt	650° (343°)	780	100 (22.7)	200 (13.8) >20 cSt	650° (343°)	520	65 (14.8)	150 (10.3) >550 cSt	500° (260°)
G3-32	780	100 (22.7)	200 (13.8) >20 cSt	400° (204°)	-	-	-	-	-	-	-	-
G1-55	640	135 (30.7)	200 (13.8) >20 cSt	650° (343°)	640	135 (30.7)	200 (13.8) >20 cSt	650° (343°)	420	90 (20.4)	150 (10.3) >550 cSt	500° (260°)
G2-55	640	135 (30.7)	200 (13.8) >20 cSt	650° (343°)	-	-	-	-	-	-	-	-
G3-55	640	135 (30.7)	200 (13.8) >20 cSt	400° (204°)	-	-	-	-	-	-	-	-
G1-69	520	140 (31.8)	200 (13.8) >20 cSt	650° (343°)	520	140 (31.8)	200 (13.8) >20 cSt	650° (343°)	420	110 (25.0)	150 (10.3) >550 cSt	500° (260°)
G2-69	520	140 (31.8)	200 (13.8) >20 cSt	650° (343°)	-	-	-	-	-	-	-	-
G3-69	520	140 (31.8)	200 (13.8) >20 cSt	400° (204°)	-	-	-	-	-	-	-	-
G1-82	640	200 (45.4)	200 (13.8) >165 cSt	500° (260°)	640	200 (45.4)	200 (13.8) >165 cSt	500° (260°)	520	160 (36.3)	125 (8.6) >550 cSt	500° (260°)
G2-82	640	200 (45.4)	200 (13.8) >165 cSt	500° (260°)	-	-	-	-	-	-	-	-
G3-82	640	200 (45.4)	200 (13.8) >165 cSt	400° (204°)	-	-	-	-	-	-	-	-
G1-133	520	300 (68.1)	200 (13.8) >165 cSt	500° (260°)	520	300 (68.1)	200 (13.8) >165 cSt	500° (260°)	350	200 (45.4)	125 (8.6) >25 cSt	500° (260°)
G2-133	520	300 (68.1)	200 (13.8) >165 cSt	500° (260°)	-	-	-	-	-	-	-	-
G1-222	520	500 (113.6)	200 (13.8) >165 cSt	500° (260°)	520	500 (113.6)	200 (13.8) >165 cSt	500° (260°)	350	320 (72.7)	125 (8.6) >25 cSt	500° (260°)
G2-222	520	500 (113.6)	200 (13.8) >165 cSt	500° (260°)	-	-	-	-	-	-	-	-

(1) Maximum pressure listed reflects maximum differential pressure and maximum allowable working pressure.

(2) Values listed in table are nominal and for reference only. To ensure proper pump selection, always refer to Blackmer Select.

SPECIFICATIONS: PUMP JACKETING

Model Number	Maximum Temperature/Pressure of Fluid in Jackets							
	Steam (Saturated)				Heat Transfer Oil			
	Temperature		Pressure		Temperature		Pressure	
	°F	°C	PSIG	Bar	°F	°C	PSIG	Bar
G2-55	365	185	150	10.4	450	232	150	10.4
G2-69	365	185	150	10.4	450	232	150	10.4
G2-82	365	185	150	10.4	450	232	150	10.4
G2-133	365	185	150	10.4	450	232	150	10.4
G2-222	365	185	150	10.4	450	232	150	10.4

(1) Ports are suitable for use with 125# ANSI cast or ductile iron or 150# ANSI steel companion flanged fittings. All other tapped for standard pipe (NPT).

(2) For use at higher temperatures. consult factory for recommended materials of construction.

How It Works—Internal Gear Technology


The G SERIES GEAR PUMP is a rotating, positive displacement pump. These drawings show the flow pattern through the pump upon its initial rotation. It is assumed that the pump has no fluid in it prior to its initial rotation.

1

The shaded area indicates the liquid as it is drawn into the liquid inlet port of the pump. As the rotor turns, atmospheric pressure forces the liquid between the rotor teeth and idler teeth. The two arrows indicate the rotational direction of the pump.

2

As the rotor continues to turn, the liquid is forced through the crescent-shaped area of the wetted path. The crescent-shaped area divides the liquid and acts as a barrier between the inlet and discharge ports.

**3**

As the rotor continues to turn, the liquid is forced past the crescent-shaped area and moves toward the discharge port.

4

As the rotor completes one complete rotation, the rotor and idler teeth interlock, forcing the liquid through the discharge of the pump. The pump may take several rotations to completely prime depending on the conditions of the application.

Suggested Installation and Operation

G Series gear pumps are designed to meet the performance requirements of even the most demanding pumping applications. They have been designed and manufactured to the highest standards and are available in a number of different sizes to meet your pumping needs. Refer to the performance section of this manual for an in-depth analysis of the performance characteristics of your pump.

INSTALLATION

Months of careful planning, study and selection efforts can result in unsatisfactory pump performance if installation details are left to chance.

Premature failure and long-term dissatisfaction can be avoided if reasonable care is exercised throughout the installation process.

LOCATION

Noise, safety and other logistical factors usually dictate where equipment will be situated on the production floor. Multiple installations with conflicting requirements can result in congestion of utility areas, leaving few choices for additional pumps.

Within the framework of these and other existing conditions, every pump should be located in such a way that key factors are balanced against each other to maximum advantage.

ACCESS

The location of the pumping unit should be accessible. If it's easy to reach the pump for maintenance, personnel will have an easier time carrying out routine inspections and adjustments. Should major repairs become necessary, ease of access can play a key role in speeding the repair process and reducing total downtime.

FOUNDATION

BASEPLATES AND ANCHORS

The preferred mounting for a baseplate is on a concrete pad with grouting. No matter how robust the design, there is always some flexibility in the baseplate itself. If there is insufficient support under the baseplate, it can distort causing alignment difficulties and normal vibrations can be amplified to unacceptable levels through resonance in the pump support and/or piping. A properly grouted baseplate will resist distortion and will provide sufficient mass to dampen any vibration.

NOTE: When pumps and motors are assembled on a baseplate at the factory, a preliminary alignment is done to ensure that the pump and motor can be aligned at its installation. This alignment is not to be considered as a final alignment. The factory alignment can, and does, change during shipment and when the pumping unit is installed. Actually, several alignments are necessary, as will be described later.

Anchor (foundation) bolts are used to hold the baseplate to its support structure, whatever that may be. In the preferred case of mounting the pump unit on a concrete pad, the anchor bolts are set into the pad as indicated in the following illustration. When pouring the pad, it's helpful to have a wooden template attached to the foundation form to position the anchor bolts at their locations as indicated on the pump unit assembly drawing.




FIGURE A – TYPICAL ANCHOR BOLT (SLEEVE TYPE)

Anchor bolts are usually sized smaller than the anchor bolt hole size in the base. Calculate bolt length as indicated in Figure A on the left.

The ID of the sleeve should be two bolt sizes larger than the anchor bolt.

Allow approx. $\frac{3}{4}$ " - $1\frac{1}{2}$ " space between the bottom edge of the baseplate and the foundation for grouting.

A "Sleeve" type anchor bolt is shown here. Alternatively, a "hook" or "J" type anchor bolt may be used.

Pack the space between the anchor bolt and sleeve to prevent concrete and/or grout from entering this area.

BASE INSTALLATION AND GROUTING

NOTE: Before the baseplate is installed, it is advisable to thoroughly clean the underside to enable the grouting to adhere to it. Do not use oil-based cleaners since grout will not bond to it.

Once the concrete pad has cured, the baseplate can be carefully lowered over the anchor bolts.

Place shims or tapered wedges under the baseplate at each of the anchor bolt positions to provide about 0.75" – 1.50" clearance between the base and the foundation. Adjust shims/wedges to level the baseplate. **Since there may be some flexibility in the baseplate, we must perform an initial alignment prior to grouting to ensure that a final alignment can be achieved. See section covering Alignment of Pump/Driver Shafts.** Potential problems here include bowing and/or twisting of the baseplate. If gross misalignment is observed, shims/wedges may have to be added under the mid-point of the base or the shims/wedges at the corners may have to be adjusted to eliminate any twist. If the driver feet are bolt-bound for horizontal alignment, it may be necessary to loosen the pump hold-down bolts and shift the pump and driver to attain horizontal alignment. When alignment has been achieved, lightly tighten the anchor bolts. The anchor bolts should not be fully tightened until the grout has set.

Grouting furnishes support for the pump unit baseplate providing rigidity, helping to dampen any vibration and serves to distribute the weight of the pump unit over the foundation. To be effective, grouting must completely fill all voids under the baseplate. For proper adhesion or bonding, all areas of the baseplate that will be in contact with the grout should be thoroughly cleaned. See note above. The grout must be non-shrinking. Follow the directions of the grout manufacturer for mixing. Proceed with grouting as follows:

NOTE: If the size of the equipment or the layout of the installation requires it, grouting can be done in two steps as long as the first step is allowed to cure completely before the second step is applied

1. Build a sturdy form on the foundation around the baseplate to contain the grout.
2. Soak the top of the concrete foundation pad thoroughly. Remove surface water before pouring.
3. Pour the grout through the hole(s) in the top and/or through the open ends of the channel steel baseplate, eliminating air bubbles by tapping, using a vibrator or pumping the grout into place. If necessary, drill vent holes into the top of the base to evacuate air.
4. Allow grout to set completely, usually a minimum of 48 hours.
5. Tighten foundation anchor bolts.
6. Recheck alignment to ensure that there have been no changes.
7. After the grout has dried thoroughly, apply an oil base paint to shield the grout from air and moisture.

PIPING

Final determination of the pump site should not be made until the piping challenges of each possible location have been evaluated. The impact of current and future installations should be considered ahead of time to make sure that inadvertent restrictions are not created for any remaining sites.

The best choice possible will be a site involving the shortest and straightest hookup of suction and discharge piping. Unnecessary elbows, bends and fittings should be avoided. Pipe sizes should be selected to keep friction losses within practical limits.

All piping should be supported independently of the pump. In addition, the piping should be aligned to avoid placing stress on the pump fittings. To eliminate possible closing of the line when performing pump maintenance, a gate valve should be installed at the suction line.

G Series gear pumps are positive displacement pumps; as such, care must be used in protecting piping and components used in your system. Pumps equipped with an internal relief valve are designed to protect the pump only. A system relief valve should be installed along with the pump's internal relief valve.

When placing the pump, choose a location as close to the product source as possible. Care should be taken in your supply line to avoid cavitation due to viscosity and suction lift. **NOTE:** Some liquids may become thicker with temperature changes. Please refer to your supplier of product being pumped for information on viscosity changes due to temperature. Avoid air pockets on suction side of pump when designing piping layout. This will also reduce the possibility of cavitation. The weight of the piping should not be supported or absorbed by the pump. Suction and discharge piping should be supported by pipe hangers or another suitable means.

G SERIES GEAR PUMPS ARE NOT SUITED FOR PUMPING DIRTY, SOLID-LADEN LIQUIDS. A strainer should be used on the suction side of the pump. The strainer should consist of an adequate size mesh screen as to not cause excessive friction loss. It is suggested that a maintenance program is created to assure that the inlet strainer remains free of obstructions and blockage.

ALIGNMENT OF PUMP/DRIVER SHAFTS

WARNING!

NOTE: Driver power must be locked out before beginning any alignment procedure. Failure to lock out driver power may result in serious physical injury.

NOTE: Proper alignment is the responsibility of the installer and user of the equipment.

NOTE: Check alignment if process temperature changes, piping changes and/or pump service is performed.

Pump and driver shafts need to be aligned for both parallel and angular alignment. If there is a misalignment of the shafts, it will place a mechanical load on the pump and driver shaft/bearing assemblies as well as the coupling. This will result in vibration, noise and premature failures. Furthermore, due to the tight internal clearances of the G-Series pump, misalignment can cause deflection of the rotor into the stationary case or head. This can cause premature wear that will increase clearances, lead to decreased pump performance and potentially lead to pump failure. This is particularly important for stainless steel pumps.




FIGURE B – PARALLEL MISALIGNMENT




FIGURE C – ANGULAR MISALIGNMENT

To bring shafts into alignment, we first need to determine the amount and direction of both parallel and angular misalignments. We can then shim and reposition to correct.

It's preferable to shim **ONLY** under the driver feet since good contact between the pump foot and the base is necessary to resist any pump flange loading that might be imposed by the suction and/or discharge piping.

There are three methods commonly used to determine misalignment:

1. Straight edge and calipers or inside micrometer (least accurate)
2. Dial indicator (reasonably accurate)
3. Laser alignment equipment; see manufacturer's instructions for use

Since any misalignment will impose loads on the pump and driver shafts, the objective is to minimize any misalignment in order to protect the pump and driver and minimize any tendency for vibration. Suggested misalignment limits are:

MISALIGNMENT LIMITS		
PUMP FRAME GROUP	MAX. PARALLEL	MAX. ANGULAR
2/4, 24/32, 55/69, 82	0.005"	0.005"
133/222	0.010"	0.010"

For optimum performance and Mean Time Between Pump Maintenance (MTBPM), use alignment limits half of those shown above.

NOTE: In any case, disregard the coupling manufacturer's published misalignment limits, as these will impose unacceptable loads on the pump and motor shafts and bearings.

Alignment must be done at several different times:

1. Prior to grouting baseplate during installation
2. After grouting baseplate and tightening anchor bolts
3. After attaching suction and discharge piping prior to initial operation
4. Hot alignment after equipment temperatures have stabilized
5. After pump maintenance bearing housing is removed

Since the G-Series pump is foot-mounted, its shaft centerline will rise when handling pumpage at elevated temperatures. Similarly, the motor shaft centerline will rise as it reaches its operating temperature. Therefore, we will often purposely misalign shafts vertically during cold alignment to allow for thermal growth, thus bringing the shafts into alignment at operating temperature. This is shown in the “COLD SETTING OF PARALLEL VERTICAL ALIGNMENT” table.

The most simple alignment check is with a straight edge and calipers or inside micrometer. This method is the least accurate, but it will serve if a dial indicator or laser is not available.

ALIGNMENT WITH STRAIGHT EDGE AND MICROMETER




FIGURE D – ANGULAR ALIGNMENT

With coupling hubs stationary, use inside micrometer or calipers to measure the gap between the coupling hubs at 90° intervals. Adjust and/or shim equipment until the gap difference at all points around the hub(s) is less than the value shown in the “MISALIGNMENT LIMITS” table.




FIGURE E – PARALLEL MISALIGNMENT

With coupling hubs stationary, lay straight edge flat against rim of coupling hub to determine vertical and horizontal alignment offsets. Adjust and/or shim equipment until the straight edge lies flat against both hub rims, vertical and horizontal.

DIAL INDICATOR METHOD




FIGURE F – DIAL INDICATOR SETUP

The dial indicator method is preferred for checking alignment.

1. Scribe or mark index lines on both coupling hubs to indicate where the dial indicator point rests.
2. Set dial indicator to zero.
3. Slowly turn BOTH coupling hubs so that the index lines match or the indicator point is always on the mark.
4. Observe dial reading to determine required adjustments.
5. Acceptable parallel and angular alignment occurs when the total indicator reading (TIR) for a complete turn does not exceed the values shown in the “MISALIGNMENT LIMITS” table.

LASER ALIGNMENT METHOD:

The laser alignment method is preferred for checking alignment.

Laser alignment is usually the most accurate method. Follow the laser alignment equipment manufacturer's instructions for this method.

As previously mentioned, pump and motor shafts need to be in alignment while they are at their intended operating temperature. When the shafts are aligned “cold” (at ambient temperature), we will intentionally position the motor shaft up or down in vertical parallel alignment to allow for thermal growth. Then, when the alignment is checked “hot” (at stable operating temperature), the shafts should be confirmed to be in alignment. Use the values in the following table as starting point for cold alignment settings. The actual cold alignment setting will be determined after the hot alignment is performed.

PORT ORIENTATION AND SHAFT ROTATION

COLD SETTING OF PARALLEL VERTICAL ALIGNMENT	
PUMPAGE TEMPERATURE	SET DRIVER SHAFT, INCHES
10°C (50°F)	0.002" LOW
66°C (150°F)	0.001" HIGH
121°C (250°F)	0.005" HIGH
177°C (350°F)	0.009" HIGH
232°C (450°F)	0.013" HIGH
288°C (550°F)	0.017" HIGH
343°C (650°F)	0.021" HIGH

G Series pumps can be operated in either a clockwise or counterclockwise rotation. The shaft rotation determines which port is suction or discharge.

PRESSURE RELIEF VALVES

- G Series pumps are positive displacement pumps, which means the system must have provisions for pressure relief protection, such as a relief valve mounted directly on the pump or inline with the system. Alternatively, the system can be installed with a torque-limiting device or a rupture disk.
- If the system requires the pump to operate in both directions, pressure relief protection is required on both sides of pump.
- When using an integral relief valve, the adjusting screw cap must always point towards the suction side of pump. If shaft rotation has to be reversed, simply remove the pressure relief valve and reinstall it in the proper configuration to avoid over-pressurization of the system.
- Pressure relief valves are not intended to control pump flow or regulate discharge pressure.
- The pump-mounted integral relief valve should never be relied upon for system protection.

START UP

- Check to ensure that the pressure/vacuum gauges are installed on inlet and discharge side of the pump.
- Check to ensure that installation and piping are correctly fastened and supported.
- Check to ensure that the pump and driver are properly aligned. Refer to "Alignment" section.
- Verify that the motor is wired correctly. Check to ensure that the thermal overload relays are properly sized and set for operation.
- With motor/driver locked out, check that the pump rotates by hand.
- Jog motor to validate correct rotation.
- Check to ensure that the coupling guard and all other safety-related devices and instrumentation are in place and in working order.
- Check to ensure that the pressure relief valve is installed correctly.
- Lubricate any grease fittings and/or bearings.
- Open suction, discharge and any auxiliary valves, such as in-line PRV loops, to ensure proper flow into and out of pump.
- Prime pumping chamber and seal chamber, if possible.
- If pump handles pumpage at temperature greater than 93°C (200°F), the pump should be gradually warmed until its temperature is within 38°C (100°F) of intended operating temperature.
- Start pump. If flow is not achieved in 30 seconds shut-off immediately. "Dry" running a pump for extended periods of time will damage the pump. If fluid does not start to flow in 30 seconds, revisit the previous steps. If every step has been followed, manually fill the pump with the process fluid or a lubricating fluid compatible with the process and restart the pump. If no fluid is flowing within 30 seconds shut the pump down and proceed to troubleshooting section of this document.
- One pump is operational, listen for any untoward noise, check for any significant vibration or indications of binding. If any of these are observed, the pump should be stopped immediately and a thorough check of the installation should be made to determine the cause. Correct any fault(s) prior to re-starting the pump.
- Check the shaft seal. If pump has mechanical seal(s), there should be no visible leakage. If pump has packing, there should be a steady leakage stream. Packing leakage should be reduced gradually by tightening the gland nuts ¼-turn at a time until a leakage rate of 40-60 drops per minute is achieved. This may take several hours and several adjustments, but it is required to ensure adequate packing and shaft life.

Maintenance**GENERAL MAINTENANCE**

WARNING: For G Series pumps equipped with jacketed casing, ensure pump is fully cooled prior to conducting inspection, repair, or maintenance.

CLEANING: G Series pumps must be maintained and kept as clean as possible. This will allow for quick inspection, adjustment and repair work.

LUBRICATION: Use multi-purpose NLGI #2 grease on all lubrication fittings every 500 hours of operation. Do not over-grease. Applications involving extreme temperatures (high or low) may require other types of lubrication. Consult factory for specific lubrication recommendations.

STORAGE: If a pump is to be stored for more than six (6) months, the pump must be drained prior to storing. A light coat of light oil should be applied to all internal pump parts in order to prevent corrosion. Operators should also lubricate the fittings and apply grease to the pump shaft, while periodically rotating the pump shaft by hand one (1) complete revolution every 30 days to circulate the oil. Be sure to inspect the fastener torque before putting the pump in service after being stored.

PACKING MAINTENANCE

PACKING ADJUSTMENT: Newly packed pumps require initial packing adjustments to control leakage. Small initial adjustments are needed to prevent over-tightening the packing gland. After initial startup, additional adjustments may be required. Finally, the packing should also be checked periodically and adjusted. Refer to "Start Up" section for more detail.

REMOVAL

1. Remove packing gland fasteners.
2. Slide the packing gland out of the stuffing box.
3. Remove the packing.
4. Remove packing retaining washer.

INSTALLATION

1. Ensure packing is chemically compatible with the liquid being pumped; consult with factory recommendations.
2. Install packing retaining washer in the gland.
3. Lubricate packing rings with oil, grease or graphite to aid with assembly.
4. Stagger the packing joints from one side of the shaft to the other. The joints of adjacent strands should never be in line with each other.
5. Install the packing gland, fasteners and nuts.
6. Ensure that the gland is installed squarely and that the nuts are tightened evenly.
7. Tighten the nuts until packing gland contacts packing. Final adjustment should be made per "START UP" procedure.

COMPONENT SEAL MAINTENANCE (G1 PUMPS)**REMOVAL**

1. Remove bearing housing (see Disassembly Section).
2. If installed, remove all flush lines
3. Remove packing gland fasteners.
4. Slide the packing gland out of the stuffing box.
5. Remove the seal components.
6. Remove the pipe plug in the bracket.
7. Loosen the two (2) set screws on the mechanical seal collar.
8. Remove the mechanical seal collar.

INSTALLATION

NOTE: Never touch mechanical seal faces with anything except clean hands or a clean cloth. Small particles can scratch and damage the seal faces, resulting in seal leakage.

1. Clean the rotor shaft and the seal housing bore. Make sure they are free of dirt, burrs and scratches. Using emery paper, gently smooth the leading edge of the shaft's diameter.
2. A tapered sleeve is required over the shaft locknut threads to prevent damage of the seal during installation. Slide the tapered sleeve on to the shaft.
3. Coat the tapered sleeve and the inside diameter of the rotary members of the seal generously with light oil.
4. Place the rotary member of the seal onto the shaft over the tapered sleeve (mechanical seal collar first). Position the rotary member so that the set screws of the mechanical seal collar are directly in-line with the seal access hole on the side of the bracket. For Type 1 seals, use the second hole from the seal housing bore face. For Type 9 seals, use the first hole from the seal housing bore face. For all other seal types, use the seal manufacturer's recommended working height when setting the mechanical seal collar. Do not tighten the seal collar set screws at this time.
5. Install the stationary seal face followed by the seal gland loosely onto the shaft. Do not install gland nuts at this time.
6. Reinstall the bearing housing (see Reassembly Section).
7. Adjust the end clearance (see Reassembly Section).
8. After the rotor end clearance is set, ensure the mechanical seal collar is directly in line with the proper seal access hole and tighten the mechanical seal collar using two (2) or four (4) set screws, depending upon seal type.
9. Install pipe plug on bracket.
10. For stationary O-ring seal seats, lubricate the outer diameter of the O-ring with light oil.
11. Install the stationary seal face.
12. Install the packing gland, fasteners and nuts.
13. Tighten nuts securely and evenly.
14. As required, connect flush line.

COMPONENT SEAL MAINTENANCE (G3 PUMPS)

REMOVAL

1. Remove bearing housing (see Disassembly Section).
2. Remove head and idler (see Disassembly Section).
3. Carefully slide out rotor shaft taking care to not damage bushing or lip seal in bracket.
4. Remove stationary seat from bracket and rotating seal from rotor shaft.

INSTALLATION

NOTE: Never touch mechanical seal faces with anything except clean hands or a clean cloth. Small particles can scratch and damage the seal faces, resulting in seal leakage.

1. Clean the rotor shaft and the seal housing bore. Make sure they are free of dirt, burrs and scratches. Using emery paper, gently smooth the leading edge of the shaft's diameter.
2. A tapered sleeve is required to slide the seal over the step in the shaft. It may also be helpful to apply take over threads on shaft to protect rotating seal.
3. Coat the tapered sleeve, shaft, and the inside diameter of the rotary members of the seal generously with light oil.
4. Place the rotary member of the seal onto the shaft and slide until spring washer is resting against the backside of the rotor. Tighten any setscrews into the shaft with collar of rotating seal against the rotor. Not all seal types use set screws.
5. Generously coat the shaft with light oil and apply grease to inside of the bushing.
6. Slide rotor shaft carefully into the bracket taking care to not damage seal faces or bushing.
7. Do not slide the seal install collar through the bushing, it may scratch the bushing. To get the shaft step past the lip seal it is possible with care, or removing the lip seal and reinstalling once shaft is in place.
8. Reinstall the bearing housing (see Reassembly Section).
9. Adjust the end clearance (see Reassembly Section).
10. Apply grease to the zerk closer the bracket lip seal until grease comes from the opposite hole.
11. Apply grease to the zerk closer to the case until grease comes from the same hole as before. Install a relief in this hole.

CARTRIDGE SEAL MAINTENANCE (G1 PUMPS)

REMOVAL

1. Remove bearing housing (see Disassembly Section).
2. If installed, disconnect all flush lines or barrier fluid tubes.
3. Loosen the set screws on the seal collar to free the cartridge seal from the shaft.
4. Remove the two (2) gland fasteners.
5. Slide cartridge seal out through bearing housing.

INSTALLATION

1. Clean the rotor shaft and the seal housing bore. Make sure they are free of dirt, burrs and scratches. Using emery paper, gently smooth the leading edge of the shaft's diameter.
2. A tapered sleeve is required over the shaft locknut threads in order to prevent damage to the seal during installation. Slide the tapered sleeve on to the shaft.
3. Coat the tapered sleeve and the inside diameter of the seal generously with light oil.
4. Slide the cartridge seal over the tapered sleeve until it contacts the seal chamber face.
5. Remove the tapered sleeve from the shaft.
6. Reinstall the bearing housing (see Assembly Section).
7. Adjust the end clearance (see Assembly Section).
8. Install the gland fasteners and nuts.
9. Turn the shaft several times while the gland is loose to the center seal.
10. Tighten nuts securely and evenly.
11. Lock the cartridge seal drive collar to shaft and remove to clear the drive collar.
12. Turn shaft by hand or bump motor in order to test the rotation and to check the drive collar for run-out.
13. As required, connect flush line.

NOTE: For maximum seal life and increased seal retention, a flush line is recommended.

Disassembly

BEARING HOUSING REMOVAL

1. Insert a length of brass through the port opening and in-between the rotor teeth in order to lock the pump and secure the shaft from turning.
2. Bend the lock washer tang upwards.
3. Using a spanner wrench, remove lock nut and lock washer from shaft.
4. Loosen the two (2) set screws in the face of the bearing housing and remove the bearing housing assembly from the bracket.
5. Remove the two (2) semi-round rings under the inner spacer collar from the shaft.

NOTE: There are no semi-round rings on the G1-2, G1-4, G1-133 or G1-222 models.




FIGURE G – G1-2 THROUGH G1-82 BEARING HOUSING ASSEMBLY




FIGURE H – G1-133 THROUGH G1-222 BEARING HOUSING ASSEMBLY

WET END DISASSEMBLY

1. Mark the head and casing prior to disassembly as this will ensure proper reassembly. The idler pin must be positioned an equal distance between the port connections in order to allow for proper flow of liquid through the pump.
2. Remove the head from pump. **WARNING:** Protect the idler from falling as it may become loose during removal of the head.
3. Remove the idler and bushing assembly.
4. Remove seal or packing (see Maintenance Section).
5. Carefully remove the rotor and shaft to avoid damaging bracket bushing.
6. Remove the case from the bracket, as necessary.
7. Clean all parts thoroughly and examine the parts for wear or damage. Replace bracket bushings, idler bushings and idler pins, as necessary.

BEARING HOUSING DISASSEMBLY

1. Loosen the two (2) radial set screws from the bearing housing end cap.
2. Using a spanner wrench, loosen the bearing housing end cap.
3. Remove outer bearing spacer collar.
4. Remove the double-row ball bearing (G1-2 through G1-82 models) or tapered roller bearings (G1-133 and G-222 models).
5. Remove the inner bearing spacer collar.
6. Clean all parts thoroughly and examine the parts for wear or damage. Replace lip seals and bearings, as necessary. It is recommended to replace the lip seals whenever replacing the bearings.

PRESSURE RELIEF VALVE DISASSEMBLY

1. Place a mark on the valve and head prior to disassembly in order to ensure proper reassembly.
2. Remove the pressure relief valve cap.
3. Measure and record the extension length of the adjusting screw.
4. Loosen the pressure relief valve lock nut and then back out pressure relief valve bonnet and adjusting screw until the spring pressure is released.
5. Remove, clean and inspect all parts (i.e., bonnet, spring guide, spring and poppet) for wear or damage and replace as needed.

Reassembly

BEARING HOUSING ASSEMBLY

1. Clean all parts thoroughly.
2. Install the bearing housing lip seal. Refer to Figure G and Figure H for proper orientation.
3. Insert the bearings into the housing. It is best practice to pack the bearings with NLGI #2 multi-purpose grease (or equivalent) before installation. G1-2 through G1-82 use one (1) double-row ball bearing. G1-133 and G-222 use two (2) tapered roller bearings installed with the large end of inner races together. Refer to Figure G and Figure H for proper installation.
4. Install the bearing cap lip seal. Refer to Figure G and Figure H for proper orientation.
5. Install the end-cap into the bearing housing. For G1-133 and G1-222 models, make sure to tighten completely against the outer race of the bearing.
6. Insert the outer bearing spacer collar into the end cap.
7. Use two (2) bearing housing inserts and two (2) set screws to lock the end cap in place. **NOTE:** Bearing housing inserts must be used to prevent damage of the end cap threads.
8. Insert the inner bearing spacer collar. For G1-24 through G1-82 models, the recessed end of the inner bearing spacer collar must face rotor.

WET END ASSEMBLY

1. Clean all parts thoroughly.
2. Install the bracket bushing. If the bracket bushing has a lubrication groove, install the bushing with lubrication groove towards the bottom of the bracket. Carbon graphite bushings require additional precautions during installation to prevent cracking:
 - a. Use a press for installation.
 - b. Lightly lubricate the bushing and the bore.
 - c. Ensure bushing is aligned straight before starting.
 - d. Do not stop the pressing operation until bushing is in the proper position; starting and stopping will result in a cracked bushing.
 - e. Check bushing for cracks after installation.
3. If building G3 (B-Seal) pump, see mechanical seal assembly instructions above.
4. Install the bracket gasket on the bracket, aligning the holes with the bolt pattern.
5. Attach the case to the bracket.
6. Coat the rotor shaft assembly with light oil. If building G3 pump keep seal faces clean. Apply grease directly to the bushing.
7. Insert the end of the shaft into the bracket bushing by adjusting the shaft from right to left. Slowly push the rotor into the casing.
8. Press the idler pin into the head.

NOTE: Idler pin cooling port should face the crescent while aligning the cross port with the appropriate porting in the head casting.***

The idler pin must be recessed 0.010" - 0.030" below the face of the crescent. Refer to Figure J.*

NOTE: Install the NPT plug on the suction side of dovetail located on head casting.***




FIGURE J – IDLER PIN POSITION

9. Install the idler bushing. Carbon graphite bushings require additional precautions during installation to prevent cracking**:
 - a. Use a press for installation.
 - b. Lightly lubricate the bushing and the bore.
 - c. Ensure bushing is aligned straight before starting.
 - d. Do not stop the pressing operation until bushing is in the proper position; starting and stopping will result in a cracked bushing. Refer to Figure K for proper bushing alignment to idler gear based on idler gear material.
 - I. For models G1-2 thru G1-82 iron gears (Figure 1), the bushing is in its proper location when both ends of the bushing are flush or slightly recessed from the idler face.
 - II. For models G1-2 through G1-82 stainless steel gears, and E1-133 and E1-222 (Figure 2), the bushings should protrude per the sketch.
 - e. Check bushing for cracks after installation.




FIGURE K – IDLER BUSHING POSITION

10. Coat the idler pin with light oil.
11. Place the idler and bushing assembly on the idler pin.
12. Install the head gasket on the head, aligning the holes with the bolt pattern.
13. Install the head/idler assembly.
14. Locate the markings previously placed on the pump head and casing to ensure proper reassembly. Ensure that the idler pin is positioned equally between port connections as this will allow for liquid to flow properly through the pump. Tighten head fasteners evenly.
15. Install mechanical seal or packing (see Maintenance Section).

BEARING HOUSING INSTALLATION

1. Place a pair of semi-round rings on the shaft and slide the inner bearing spacer collar over semi-round rings to lock in place.

NOTE: There are no semi-round rings on G1-2, G1-4, G1-133 and G1-222 models.

2. Place the lock washer and lock nut on the shaft with the small end of the locknut facing the bearing. Insert a length of brass between rotor teeth to keep shaft from turning. Tighten lock nut per torque values in table below.

Pump Model	Torque Value
G1-2	81 N•m (60 ft-lbs)
G1-4	
G1-24	156 N•m (115 ft-lbs)
G1-32	
G1-55 & G2-55	
G1-69 & G2-69	
G1-82 & G2-82	190 N•m (140 ft-lbs)
G1-133 & G2-133	244 N•m (180 ft-lbs)
G1-222 & G2-222	

3. Stake one (1) tang of lock washer into the slot of lock nut after torquing. Failure to properly torque the lock nut or engage the lock washer tang could result in premature bearing failure and damage to the pump. Finally, remove the length of the brass from the gear teeth.
4. Lubricate all grease fittings with NLGI #2 multi-purpose grease.

END-CLEARANCE ADJUSTMENT

G Series pumps rely on proper internal clearances for efficient operation. The required end clearance dimension depends on the temperature and viscosity of the fluid being pumped as well as the material of construction and size of the pump. The tables below show the end clearance dimensions needed to adjust the gap between the rotor/idler and head of the G Series gear pump.

1. Loosen bearing housing set screws (2) in the face of the bearing housing flange enough so that they do not interfere with the bearing housing rotation during end clearance setting.
2. By hand or with a small spanner wrench, spin the shaft to find the rotor to head zero clearance setting.
 - a. Turn the bearing housing clockwise to move the rotor into the head, and counterclockwise to move it away from the head.
 - b. Turn the bearing housing clockwise until the shaft becomes difficult to spin with the spanner wrench or cannot be spun by hand.
 - c. Loosen the bearing housing slightly until the shaft will spin by hand with a slight drag on the head. This drag is caused by contact between the end of the rotor tooth and the head. This is the Zero Clearance point.

NOTE: Proper end clearance adjustment is very critical to pump performance and reliability. The zero setting should never be established by forcing the rotor into the head until the shaft will no longer spin. This will lead to high horsepower draw, rubbing during operation, and the potential for the pump to seize up. Never operate a G Series pump with zero clearance.

3. Make a continuous line on the bracket and bearing housing outside diameter to mark the zero clearance point. This will be the reference for zero end clearance.
4. Make another line on the bracket by measuring the correct radial distance from the first line on the bracket based on the size and clearance of the pump. The correct radial distance can be found in the End Clearance Setting Table for the appropriate size and material of pump. This second line will always be made to the left of the first line when looking from the shaft end of the pump.
5. Rotate the bearing housing counterclockwise so that the line on the bearing housing aligns with the second line on the bracket.

NOTE: Coat all threads with anti-seize compound for stainless steel, cast iron and carbon steel.

PRESSURE RELIEF VALVE ASSEMBLY

1. Clean all parts thoroughly.
2. Install the poppet.
3. Insert the required springs.
4. Insert the spring guide.
5. Install the bonnet with a gasket. Securely tighten the bonnet.
6. Install adjusting screw and lock nut.
7. Tighten the adjustment screw to original setting.
8. Install the cap and gasket. Securely tighten the gasket.
9. Attach the pressure relief valve to the head using gaskets.
10. If a new spring is installed or if the pressure setting is to be changed, the following instructions must be carefully followed:
 - a. Carefully remove the valve cap covering the adjusting screw.

- b. Loosen the adjusting screw lock nut.
- c. Install a pressure gauge in the discharge line.
- d. Turn the adjusting screw inward (clockwise) to increase pressure and outward (counterclockwise) to decrease pressure.
- e. With the discharge line valve closed (at a point beyond the pressure gauge), the gauge will show the maximum pressure (that the pressure relief valve will allow) while the pump is in operation.

CAST IRON/CARBON STEEL EXTERNALS (G1-W, G1-C)

Pump Model	Clearance	Viscosity (cSt)	TEMP C (F)	Radial Distance on OD of Bearing Housing mm (inches)	Additional Length on OD Brg. Housing for .001" End Cl. (inches)
G1-2/4 Iron and Steel Internals (G1-WW, G1-CC)	A	Up to 540	Thru 107 (Thru 225)	19.1 (0.75)	0.22
	B		108-232 (226-450)	41.4 (1.63)	
	C		233-301 (451-575)	52.6 (2.07)	
	D	540 - 5,400	302-343 (576-650)	63.8 (2.51)	
	E	5,400 - 431,000		63.8 (2.51)	
G1-24/32 Iron Internals (G1-WW, G1-WD, G1-CW, G1-CD)	A	Up to 160	Thru 107 (Thru 225)	31.8 (1.25)	0.25
	B		108-149 (226-300)	50.8 (2)	
	C		150-232 (301-450)	63.5 (2.5)	
	D	1,600 - 16,000	233-343 (451-650)	95.3 (3.75)	
	E	16,000 - 431,000		127.0 (5)	
G1-24/32 Steel Internals (G1-WC, G1-CC)	A	Up to 160	Thru 107 (Thru 225)	31.8 (1.25)	0.25
	B	160 - 1,600	108-232 (226-450)	63.5 (2.5)	
	C	1,600 - 16,000	233-343 (451-650)	95.3 (3.75)	
	D			127.0 (5)	
	E	16,000 - 431,000		127.0 (5)	
G1-55/69 & G2-55/69 Iron Internals (G1-WW, G1-CW)	A	Up to 160	Thru 107 (Thru 225)	31.8 (1.25)	0.25
	B		108-149 (226-300)	50.8 (2)	
	C		150-232 (301-450)	63.5 (2.5)	
	D	1,600 - 16,000	233-302 (451-575)	82.6 (3.25)	
	E		303-343 (576-650)	108.0 (4.25)	
	F	16,000 - 431,000		127.0 (5)	
G1-55/69 Steel Internals (G1-WC, G1-CC)	A	Up to 160	Thru 107 (Thru 225)	31.8 (1.25)	0.25
	B	160 - 1,600	108-232 (226-450)	63.5 (2.5)	
	C	1,600 - 16,000	233-301 (451-575)	82.6 (3.25)	
	D		302-343 (576-650)	127.0 (5)	
	E	16,000 - 431,000		127.0 (5)	
G1-82 & G2-82 Iron Internals (G1-WD, G1-CD)	A	Up to 160	Thru 107 (Thru 225)	31.8 (1.25)	0.25
	B	160 - 1,600	108-232 (226-450)	63.5 (2.5)	
	C	1,600 - 16,000	233-301 (451-575)	95.3 (3.75)	
	D		302-343 (576-650)	127.0 (5)	
	E	16,000 - 431,000		127.0 (5)	
G1-133/222 & G2-133/222 Iron Internals (G1-WD, G1-CD)	A	Up to 160	Thru 107 (Thru 225)	78.7 (3.1)	0.31
	B	160 - 1,600	108-232 (226-450)	118.1 (4.65)	
	C	1,600 - 16,000	233-343 (451-650)	157.5 (6.2)	
	D	16,000 - 431,000		196.9 (7.75)	

NOTE: For pumps with cast iron and carbon steel externals, steel rotors are recommended above the following viscosities:

	G1-2	G1-4	G1-24	G1-32	G1-55 & G2-55	G1-69 & G2-69
SSU	25,000	7,500	25,000	75,000	25,000	2,500
cSt	5,500	1,650	5,500	16,500	5,500	550

STAINLESS STEEL EXTERNALS (G1-S)

Pump Model	Clearance	Viscosity (cSt)	TEMP C (F)	Radial Distance on OD of Bearing Housing mm (inches)	Additional Length on OD Brg. Housing for .001" End Cl. (inches)
G1-2/4 Stainless Steel Internals (G1-SS)	A	Up to 540	Thru 107 (Thru 225)	28.4 (1.12)	0.22
	B		108-149 (226-300)	56.4 (2.22)	
	C	540 - 5,400	150-260 (301-500)	73.2 (2.88)	
	D	5,400 - 431,000		73.2 (2.88)	
G1-24/32 Stainless Steel Internals (G1-SS)	A	Up to 1,600	Thru 107 (Thru 225)	50.8 (2)	0.25
	B		108-177 (226-350)	82.6 (3.25)	
	C	1,600 - 16,000	178-260 (351-500)	114.3 (4.5)	
	D	16,000 - 431,000		146.1 (5.75)	
G1-55/69 Stainless Steel Internals (G1-SS)	A	Up to 1,600	Thru 107 (Thru 225)	50.8 (2)	0.25
	B	1,600 - 16,000	108-177 (226-350)	82.6 (3.25)	
	C		178-260 (351-500)	114.3 (4.5)	
	D	16,000 - 431,000		146.1 (5.75)	
G1-82 Stainless Steel Internals (G1-SN)	A	Up to 160	Thru 107 (Thru 225)	63.5 (2.5)	0.25
	B	160 - 1,600	108-163 (226-325)	95.3 (3.75)	
	C	1,600 - 16,000	163-260 (326-500)	127.0 (5)	
	D	16,000 - 431,000		158.8 (6.25)	
G1-133/222 Stainless Steel Internals (G1-SN)	A	Up to 1,600	Thru 135 (thru 275)	78.7 (3.1)	0.31
	B	1,600 - 16,000	136-260 (276-500)	118.1 (4.65)	
	C	16,000 - 431,000		196.9 (7.75)	

Troubleshooting

PUMP RUNS, BUT LITTLE PRODUCT FLOWS

- Pump speed is too slow.
- Suction piping strainer is too small or obstructed.
- Suction pipe or port is not immersed deep enough within the liquid.
- Piping is improperly installed, permitting air pockets to form in the pump.
- Increased clearances or wear in the pump can cause the pump to deliver an insufficient supply of liquid.
- Air leaks in the suction line.
- Suction losses are too great. The suction lift is too great or the suction line is too small or too long. This can be detected by installing a vacuum gauge directly at the pump suction. The maximum vacuum at the pump suction should never exceed 381 mm-Hg (15 in-Hg). Vaporization caused by higher vacuums will generally result in a reduction of capacity.
- Improper orientation of the head.

PUMP RUNS BUT NO PRODUCT FLOWS

- Leaks in suction line or port passage. These can be detected by submerging the pressure line from the discharge side of the pump.
- Direction of shaft rotation is incorrect.
- Relief valve setting is too low. Liquid is discharging through the by-pass port.
- The net-positive suction head available (NPSHa) is lower than required for the vapor pressure of the liquid pumped. Recalculate the NPSHa and redesign piping, if necessary.
- Improper orientation of the head.

PUMP OPERATION IS ERRATIC OR INCONSISTENT

- Inconsistent suction conditions.
- Leaking suction lines.
- Pump cavitation due to air or vapor in liquid.

PUMP IS EXCESSIVELY NOISY

- The shaft is worn or bent, causing pump vibration.
- There is an air leak on suction line.
- Cavitation in the pump is occurring.
- The coupling is too close to the pump.
- The coupling is misaligned.

PUMP IS LEAKING

- Retighten all fasteners.

NOTE: Packed gear pumps are designed to leak slightly to prevent excessive heat build-up. An expected leak rate for packed gear pumps is a few drops per minute; more than this may indicate a problem.

CAUTION: When pumping hazardous liquids, a mechanically sealed gear pump is suggested to minimize any potential source of leakage that could result in a hazardous condition.

PUMP IS DRAWING TOO MUCH POWER

- The pressure is too high.
- Drive shaft and pump are misaligned.
- Pump shaft is bent.
- Pumped liquid has a higher viscosity than originally accounted for.
- Suction or discharge lines are obstructed or restricted.
- Insufficient horsepower.
- Insufficient end clearance, therefore pump is binding.

Warranty

Each and every product manufactured by Blackmer® is built to meet the highest standards of quality. Every pump is functionally tested to insure integrity of operation.

Blackmer warrants that internal gear pumps, accessories and parts manufactured or supplied by it to be free from defects in material and workmanship for a period of five (5) years from date of installation or six (6) years from date of manufacture, whichever comes first. Failure due to normal wear, misapplication, or abuse is, of course, excluded from this warranty.

Since the use of Blackmer equipment is beyond our control, we cannot guarantee the suitability of any pump or part for a particular application and Blackmer shall not be liable for any consequential damage or expense arising from the use or misuse of its products on any application. Responsibility is limited solely to replacement or repair of defective Blackmer products.

All decisions as to the cause of failure are the sole determination of Blackmer.

Prior approval must be obtained from Blackmer for return of any items for warranty consideration and must be accompanied by the appropriate MSDS for the product(s) involved. A Return Goods Tag, obtained from an authorized Blackmer distributor, must be included with the items which must be shipped freight prepaid.

The foregoing warranty is exclusive and in lieu of all other warranties expressed or implied (whether written or oral) including all implied warranties of merchantability and fitness for any particular purpose. No distributor or other person is authorized to assume any liability or obligation for Blackmer other than expressly provided herein.

PLEASE PRINT OR TYPE AND SEND TO BLACKMER

PUMP INFORMATION				
Item # _____		Serial # _____		
Company Where Purchased _____				
YOUR INFORMATION				
Company Name _____				
Industry _____				
Name _____		Title _____		
Street Address _____				
City _____	State _____	Postal Code _____	Country _____	
Telephone _____	Fax _____	Email _____	Web Address _____	
Number of pumps in facility? _____		Number of Blackmer pumps? _____		
Types of pumps in facility (check all that apply):		☐ Diaphragm	☐ Centrifugal	☐ Gear
		☐ Submersible	☐ Lobe	
		☐ Other _____		
Media being pumped? _____				
How did you hear of Blackmer?	☐ Trade Journal	☐ Trade Show	☐ Internet/Email	☐ Distributor
	☐ Other _____			

ONCE COMPLETE, SEND TO GR-CustomerSupport@PSGDover.com

PSG Grand Rapids
1809 Century Avenue SW
Grand Rapids, MI 49503 USA
P: +1 (616) 241-1611 • F: +1 (616) 241-3752
info@blackmer.com
blackmer.com



Where Innovation Flows

PSG® reserves the right to modify the information and illustrations contained in this document without prior notice. This is a non-contractual document. 05- 2018