

# OPERATOR'S MANUAL

## **SBM 75**

### **P.D. METER**

### **ALUMINIUM EXECUTION**

**CODE: MA/026/00/EN**  
**REV: 04A**  
**DATE: 07/2009**

---

#### **ISOIL IMPIANTI spa – Italy**

Sede e Stabilimento  
Head office and factory  
**24061 Albano S. Alessandro (BG)**  
74, via Madonna delle Rose  
Tel. +39 035 4239.011  
Fax +39 035 582078  
E-mail: [albano@isoil-impianti.it](mailto:albano@isoil-impianti.it)  
[www.isoilmeter.com](http://www.isoilmeter.com)

Uffici commerciali  
Sales office  
**20092 Cinisello Balsamo (MI)**  
27, via F.lli Gracchi  
Tel. +39 035 4239.011  
Fax +39 02 66012457  
E-mail: [sales@isoil-impianti.it](mailto:sales@isoil-impianti.it)

Sede legale  
Registered office  
**20124 Milano**  
24, viale Vittorio Veneto  
Capitale soc. i.v. Euro 774.00  
Codice fisc. E part. IVA 13066900153  
C.C.I.A.A. MI – Reg. Impr. 86449/2000





1	Introduction .....	1
1.1	Warranty .....	1
1.2	Introduction .....	1
1.3	Working principles .....	1
2	General safety principles.....	2
2.1	General instructions.....	2
2.2	Meter operation.....	3
2.3	Instructions for the operator .....	3
2.4	Servicing instructions .....	3
2.5	Operating precautions .....	4
3	Installation .....	5
3.1	Precautions.....	5
3.2	Start-up precautions .....	6
4	Maintenance.....	7
4.1	Disassembly .....	7
4.1.1	Main components disassembling .....	7
4.1.2	Rotor disassembling .....	8
4.2	Assembly .....	8
4.3	Storing .....	8
4.4	Calibrating mechanism (only for mechanical counter) .....	8
4.4.1	Calibration of flow meter (see Fig.2).....	9
4.4.2	Suggested lubricating oils for calibrating mechanism.....	9
4.5	Strainer/air separator .....	10
4.5.1	Strainer.....	10
4.5.2	Air vent valve.....	10
4.6	Tests after overhaul .....	10
4.7	Extraordinary maintenance .....	11
4.8	Spare parts .....	11
4.9	Maintenance schedule .....	11
4.10	Troubleshooting .....	11
5	Special Tool .....	13
6	Technical data.....	14

## **OPTIONAL:**

Strainer air separator  
Preset valve + check  
Calibrating mechanism for mechanical counter  
Gearing box for electronic counter VEGA

## **ENCLOSED:**

Overall dimensions with mechanical counter .....	Dwg.4251
Overall dimensions with EM6422 .....	Dwg.5302-3
SBM75 P.D. meter assembly .....	Dwg.6474-M
SBM75 P.D. meter assembly with air vent valve .....	Dwg.6474-1M
Preset valve assembly .....	Dis.6474-2M
Vane assembly.....	Dwg.6063
Air vent valve.....	Dwg.565-M
Calibration mechanism.....	Dwg.672/75
Gearing box for mounting with VEGA counter .....	Dwg.3958

*ISOIL IMPIANTI updates own products without condition of advance notice. ISOIL IMPIANTI doesn't take liabilities for use the dates that are modified*

# 1 Introduction

## 1.1 Warranty

Each device comes with a 1-year warranty, starting from the delivering date.

Such warranty of good operating of the equipments includes our efforts of repairing or replacing, in the shortest time, the parts that fail for defective manufacturing or material during the warranty period, without rights to any refund for damages or other expenses.

If a device is going to be transferred in our laboratory for repair, the delivery expenses is at the customer's expense.

For any inspection of our qualified personnel related to what stated above, the labor is at our expenses, while the board, lodging and travel expenses are in charge at the customer.

The components furnished and installed, but not produced, by Isoil

Impianti S.p.A. are covered by the guarantee released by the respective producers.

The warranty ceases if non-original spare parts are used; the warranty ceases too for an improper use or if the operational limits of the device are exceeded.

## 1.2 Introduction

ISOIL positive displacement meters are precision measuring instruments designed for use with a variety of petrochemical products and liquids. Each meter is fully tested and calibrated by factory before dispatch, and a regular service will maintain a high standard of performance and accuracy.

P.D. meters must be periodically tested by a calibrating tank, Prover, or Master Meter: if out of accuracy a service is necessary.

Experience has shown that mechanical defects are usually caused by the entry of foreign matters into the metering compartment due to inadequate straining facilities in the pipeline.

Special tools have been designed to facilitate overhaul operations and their use is recommended.

## 1.3 Working principles

Liquid enters the meter through the manifold and causes the rotor to revolve by pressure on the vanes. (fig.1)

The proximity of the rotor to the front and rear of the casing forms an efficient seal while the profile of the casing guides the vanes on to the measuring crescent.

The seal between vane and body is assured by the combined effects of gravity and centrifugal forces of vanes and it is assured the self-balance of clearances generated by the use too.

The rotor spindle extends through a pressure tight seal in the meter front cover into the calibrating mechanism which transmits the rotor movement to the register.




Fig.1



## **CAUTION**



**All parts under pressure must be released before disassembling the meter or its accessories for adjustment, inspection, servicing or substitution of its components.**

**Also make sure that all electric or electronic part, if present, are disconnected from its power supply.**

## **2 General safety principles**

This operator's manual contains basic safety instructions that must be followed during system installation, operation and maintenance. Failure to comply with these instructions may result in personal injury and can lead to personal, industrial or environmental accidents. Some examples of possible hazards caused by non-compliance with these instructions are:

- Failure of the system and/or some components
- Hazards to people caused by the exposition to electrical, mechanical or chemical influences
- Pollution of the environment through the leaking of hazardous substances

Therefore, follow the safety instructions described in this manual; in case of uncertainties, please contact the manufacturer.

### **2.1 General instructions**

- Read carefully the operator's manual.
- Make sure that all the personnel assigned to the installation, operation and maintenance is properly trained.
- Make sure that the contents of the operator's manual are completely understood by all personnel assigned to the operations on the system.
- Inspect parts under pressure in compliance with national regulations before the initial operation of the system.
- Make sure that the operator's manual is readily available to personnel on site.
- Follow national safety regulation in force in the location of the plant.
- Make sure that the system operates in compliance with the relevant operational limits.
- All pressure parts must be inspected and serviced in accordance with national laws in force.

## 2.2 Meter operation

- The meter must be operated only by trained and authorized personnel.
- The meter must not be operated in presence of foreign, unauthorized or not adequately trained personnel.
- The meter must be used for the purpose it is made for; the manufacturer is not responsible for any damage deriving from uses outside of the original purposes.
- The meter must be operated inside the limits fixed by the manufacturer; the manufacturer is not responsible for any damage deriving from uses outside of the operational limits of the device.

## 2.3 Instructions for the operator

- The operator must adhere to safety and accident-prevention standards currently in force in the country where the device is installed.
- The operator must not, by his own initiative, carry out any operation that is outside his competence.
- The operator must carefully comply with hazard and/or prohibition instructions contained in this manual.
- Do not use petrol, solvents or other flammable substances to clean parts. Use only approved commercial solvents that are non-flammable and non-toxic.

## 2.4 Servicing instructions

- Never carry out any maintenance, servicing or regulation before having closed the root valve, discharged the pressure from the system and disconnected the power supply to any electrical device (if present), unless explicitly stated otherwise.
- Read carefully the rating plates on the individual equipment.
- All maintenance operations, either ordinary or extraordinary, must be done by authorised and trained personnel.
- The maintenance operator must wear clothes adequate to the working environment and to the situation; in particular, loose or voluminous clothes, chains, bracelets, rings, earrings or anything that might get caught in the mechanical parts of the system should be avoided.
- The maintenance operator must wear adequate protective devices in accordance with safety and accident-prevention regulations.
- In explosive environments use only antisparking equipment.
- If the meter is connected to any electric or electronic equipment, disconnect all of them from the power supply before doing any servicing or regulation operation, unless explicitly stated otherwise in the manual.

## 2.5 Operating precautions

- The meter must always remain full of product; to achieve this, it is suggested to install the meter so that it remains below the main line.
- The line upstream the meter must be kept full of product to avoid that some air enters the meter.
- Each meter must be adjusted following the instructions supplied in the operator's manual.
- Follow the recommendations of the manufacturer when installing pumps. Pay particular attention to factors such as the use of foot valves, inlet pipes dimension and conformity with nPSH when there are suction pumps. Follow the recommendations of the manufacturer to minimize the problems due to air and vapors.
- For flashing liquids (quick gasification of the liquid) or easily vaporizing liquids at high environmental temperatures, e.g. light hydrocarbon, it is advisable the use of submerged aspirations and pipes larger than the nominal dimension of the pump.
- Thermal expansions that generate overpressures can easily damage the meters and the systems in general. Put safety valves for overpressure in every section that can be closed through regulation or isolation valves.



## **CAUTION**



**All parts under pressure must be released before disassembling the meter or its accessories for adjustment, inspection, servicing or substitution of its components.**

**Also make sure that all electric or electronic part, if present, are disconnected from its power supply.**

## **3 Installation**

### **3.1 Precautions**

The installation of the meter counter does not require any special procedure; just pay attention to the following points:

- The meter counter must be installed horizontally; for other applications a vertical arrangement is provided. In both cases the rotor axis must be kept horizontal.
- All the meter's openings are protected with covers when shipped; those must not be removed until the meter is installed on the piping
- Before the installation of the meter, it's suggested to clean thoroughly the piping to remove dirt, crusts and other foreign particles.
- Piping should not exercise strain on the meter. The meter is designed for overhang and supports should be provided only on the adjacent pipes.
- Leave space enough around the meter to ease access for adjustment, servicing and disassembly. The counter, if present, must be easily readable.
- The meter must always remain full of product; it's suggested to install the meter so that it remains always under the main line.
- The line upstream the meter must always remain full of product to avoid that air enters the meter's measure chamber; if the pipe arrangement allows reversal flow, a non-return valve must be installed.
- Flow through the meter must be regular and uniform; pulsating and irregular flows must be avoided.
- It is recommended to install flow limiting valves downstream of the meter if the flow rate can reach values higher than the maximum allowed for the meter.
- If the line pressure can reach values higher than the maximum allowed, automatic safety valves must be installed in adequate places.
- To protect meter from damages due to foreign particles in the liquid, a suitable strainer with a correct mesh number (40 mesh for oil, 60 mesh for diesel oil, 100 mesh for gasoline) must be installed upstream the meter.
- In case the rate of flow through the installation exceeds the meter maximum rated capacity, it is advisable to use a flow limiting valve, which must be installed downstream the same meter.
- Water must not flow through the meter.

- Meters must be installed in such a way that air or vapour do not enter through the liquid under measurement. It is always suggested to install an air separator just upstream the meter.
- To avoid hammer shocks which may strongly damages the meter, it is not advisable to install upstream or downstream the meter any quick closing valves.
- It is recommended to install root valves at the inlet and outlet to ease servicing operations and isolation of the meter.

## 3.2 Start-up precautions

- Before proceeding with the start-up make sure that:
  - The meter is adequately fixed.
  - All the connections are tightened.
  - Air is bled from the pipes.
- If a calibration mechanism is associated with the meter, before the start-up it must be filled with lubricating oil.
- Vent out all the air eventually present in the line.
- When the meter is operated for the first time, fill it slowly with the operating fluid by following this procedure:
  - Open slowly the upstream isolation meter or fill the meter by gravity.
  - Open slowly the downstream isolation meter letting the flow rate rise smoothly to the operating value.



## **CAUTION**



**Be very careful when starting up the meter: if the air enters the measuring chamber the rotor can easily reach high rotational speeds, leading to abnormal wear of the vanes and other components; this, in turn, will lead the meter to a major failure.**



## **CAUTION**



**All parts under pressure must be released before disassembling the meter or its accessories for adjustment, inspection, servicing or substitution of its components.**

**Also make sure that all electric or electronic part, if present, are disconnected from its power supply.**

## **4 Maintenance**

Before removing the flow meter from the pipeline for repairs, it is recommended that the possible causes and corrective actions are noted with the help of Fault Diagnosis Chart given in this manual.

Note that certain components in the flow meter assembly are not interchangeable. Therefore, if more that one flow meter is dismantled, it is recommended that each flow meter is dismantled independently.

**CAUTION:** Be very careful when you start up the meter after maintenance: if the air enters the measuring chamber the rotor can easily reach high rotational speeds, leading to abnormal wear of the vanes and other components; this, in turn, will lead the meter to a major failure. See chap.3.2 for start-up precautions.

### **4.1 Disassembly**

The flow meter may be considered as two main assemblies: the measuring chamber and the calibrating mechanism. To separate these two assemblies from each other, remove the screws securing the calibrating mechanism on the flow meter body.

**CAUTION:** Before dismantling the meter for maintenance release pressure from the line and drain all the fluid inside the meter through the draining hole below the meter.

Proceed then with the maintenance of the faulty part.

#### **4.1.1 Main components disassembling**

- To ensure stability during the dismounting, it is advisable to use our "Ring Support tool" (see special tool).
- Remove the sealings and the screws of the counter, unscrew the screws fixing the calibrating mechanism and after the removal of the transmission spindle, take off the transmission spindle pin.
- Remove all nuts, bolts and washers of the front cover.
- Remove the front cover using the "Cover Removal Tool" (see special tool).
- Remove the rotor group by using the "Rotor removal and turning tool" (see special tool). Turn the rotor so that two graphite vanes re-enter in the rotor in correspondence of the smaller radius.

- Extract the rotor paying attention to use the free hand to guide the rotor and control the lateral vanes movement. Don't dismount the manifold unless there are product losses or breakings.

### 4.1.2 Rotor disassembling

**NOTE:** Never remove the vanes unless they are damaged. If it is necessary to remove the vanes, before proceeding mark the position of the four vanes that correspond with the position in the rotor: that will ease the reassembly procedure. Vanes are not interchangeable and, if they can be reused, they must be placed in their original position.

- Remove the split pin placed in the opposite side of the adjusting screws.
- Remove the vane and the two washers.
- Remove the remaining vane-rods assembly.

**CAUTION:** Don't remove or loosen the the vanes adjusting nuts, since that would vary the clearance between the vanes and the measuring chamber, causing loss of performance and/or meter failure.

## 4.2 Assembly

Before assembly, clean and inspect all parts for any visual damage. Ensure that all o-ring grooves are clean and undamaged. Examine the O-Rings and ensure that they are not damaged or swollen, replace them if necessary. Examine graphite bushes on rotor assembly for free rotation and play, replace them if either is apparent. Examine each vane assembly for damage or wear, replace vane(s) if either is apparent. Examine gland seal rings in rotor assembly for damage or wear and replace if either is apparent.

The assembly procedure is the reversal of the dismantling procedure; only for installation of the internal body special precautions should be taken to match the centering cap of the external body's front cover.

## 4.3 Storing

- if after a working period it is foreseen to stop the meter for a long time, drain the meter and its accessories;
- If the meter or the equipment of the system are not immediately used, or if it is withdrawn from service and stored, it is important to follow next instructions :
  - fill the meter and its accessories with clean kerosene or lubricated oil and close its ends with blind flanges;
  - fill the carter containing the calibrating mechanism with oil till the sight glass is reached (see chap.4.4).
- adequately protect counters against rain and dust, with damp-proof caps.

## 4.4 Calibrating mechanism (only for mechanical counter)

The calibrating mechanism comprises a train of gears which transmit movement of the rotor to the counter. Operational failures of the mechanism are rare and they generally regard the breaking of tension pin, due to an excessive strain.

It is recommended to repair without varying the calibrating adjustment.

**CAUTION:** do not remove the shimming washers between the frame and the bearing of the mechanism box.

#### 4.4.1 Calibration of flow meter (see Fig.2)

To carry out meter calibration follow next procedures:

- Break and remove seals.
- Remove the three screws (1) securing the cover (2) to the housing (3) in which calibrating mechanism is fitted.
- Remove cover (2)
- By using square key (4 mm) turn shaft (4) till A, B, C holes placed on the bracket (5) and on friction roller (6) will be properly aligned.
- Insert in these holes the stop pin (supplied with the meter, then using the square key operate on the shaft (4) as follow :
  - turning counter-clockwise direction, even if the quantity of fluid does not vary, on the counter is obtained an higher volume indication;
  - turning clockwise direction it is obtained a lesser indication.




Fig. 2

**NOTE:** one complete turn of the screw varies the volume indicated on the meter by approximately 0,36% (per cent).

#### 4.4.2 Suggested lubricating oils for calibrating mechanism

Company	Type	Tempeprature range
AGIP	OTE 32 SINT 2000	-10÷+60 °C
ESSO	NUTO 32	-20÷+65 °C
IP	HINDRUS HI 46	-10÷+60 °C
SHELL	AEROSHELL FLUID 31	-40÷+204°C
MOBIL	DTE 26 MOBIL 1	-10÷+80 °C -10÷+200 °C

**NOTE:** to avoid ice forming in wintertime, add two spoons of car antifreeze.

## 4.5 Strainer/air separator

### 4.5.1 Strainer

A clean strainer is fundamental for the correct operation of the system; a dirt strainer would create an excessive pressure drop, leading to the failure of the basket and thus letting dirt, crusts and other harmful elements to flow into the fluid. If possible, check regularly the pressure drop between the inlet and the outlet of the strainer; the maximum allowed pressure drop is 130 kPa.

For a correct servicing of the basket, follow the procedure described below (dwg6474/1M):

- Discharge the pressure from the system and close the valves at the inlet and outlet
- Discharge the liquid inside the strainer air separator through the draining outlet on the bottom of the strainer
- Remove the cap
- Remove the basket and clean it thoroughly with a jet directed from inside to the outside; if possible, use a water cleaning machine
- Check accurately that the gasket is intact; if it is found to be damaged, replace with another one with the same filtering grade:

For oils with viscosity up to 20°E(150cSt):	40 mesh (433 micron)
For diesel oils:	60 mesh (247 micron)
For gasoline or water:	100 mesh (153 micron)

- Put again the wire gauze in place, close the cover and the drain valve.

It's suggested to replace the gaskets between the strainer body and the cover each time the strainer air separator is disassembled.

### 4.5.2 Air vent valve

Follow the instructions below for the servicing of the air vent valve:

- Discharge the pressure from the system and close the valves at the inlet and outlet
- Discharge the liquid inside the strainer air separator through the draining outlet
- Inspect the air vent valve, checking that it works properly and its part aren't damaged
- Close the draining valve and restore the operating conditions

## 4.6 Tests after overhaul

After overhaul the p.d. meters must be tested with suitable proving systems. Error between the value stated by the p.d.meter counter and the value stated by the proving device is calculated as below:

Example:

Measured by the meter	Measured by the proving tank	Error (%)
1000 l	1003 l	-0,3%
1000 l	997 l	+0,3%

The formula is:

$$E\% = \frac{V - V_0}{V_0} \cdot 100$$

V= Measured by the meter

V<sub>0</sub>= Measured by the proving tank

## 4.7 Extraordinary maintenance

The user must define a maintenance scheduling table according to the fluid utilised, the operational conditions, the estimated/real workloads and the environmental conditions.

For all extraordinary maintenance needed after a failure and/or the rising of a fault that compromises the normal operation of the system, please contact Isoil Impianti SpA Customer Care.

## 4.8 Spare parts

For a correct meter maintenance use only original spare parts from Isoil Impianti S.p.A. .

Isoil Impianti S.p.A. is not responsible for any problem that can result from the use of non original spare parts.

## 4.9 Maintenance schedule




Task	Monthly	6 Months	12 Months	24 Months
Visual inspection of manifold and meter body; check for leaks	X			
Inspection of the meter; check for internal part status: vanes, rotor, measure chamber, o-rings; check for wear or damage.				X

## 4.10 Troubleshooting

Symptom	Possible cause	Remedy
Liquid passing with normal flow rate but counter fails to register.	1. Defective counter.	Remove and check the counter by rotating bottom coupling. In case of any problem in the counter, contact the factory.
	2. Drive from the rotor fails to reach the counter, due to sheared pins in the calibrating mechanism.	Check cross pins fitted on all gears in the calibrating mechanism.
No liquid passing through.	1. Defective counter.	Remove and inspect the counter for free movement.
	2. Jammed calibrating mechanism.	Remove and inspect the calibrating mechanism. Identify the source of friction and replace relevant parts.
	3. Jammed rotor assembly.	Dismantle meter assembly. Inspect front & rear covers and rotor for scoring marks. Inspect vanes and bearings for damage.
	Causes of rotor jamming :	
	a. Solid particles trapped on rotor surface.	Clean the rotor surfaces.

<b>Symptom</b>	<b>Possible cause</b>	<b>Remedy</b>
	b. Incorrect adjustment of rotor end clearance due to loose or defective bearing adjuster.	Check setting of bearing adjuster. Clean and inspect the bearing adjuster.
	c. Rotor bearings jammed.	Clean bearings and cover, and inspect for any damage.
	d. Rotor bearings worn out.	Replace the bearings, if axial play is observed.
	e. Misalignment of front & rear covers due to missing dowel pins.	Ensure that both dowel pins are used for locating the covers with the body.
	4. Clogged filter basket.	Clean the filter regularly.
Liquid is leaking from the joint at front cover and calibrating mechanism.	Spindle seal is damaged.	Replace the spindle seal. Inspect rotor spindle for wear or scratch marks.
Liquid is leaking from the joint at front cover and body or rear cover and body.	Damaged o'ring seals, unclean o'ring grooves, cover bolts loose.	Clean o'ring grooves, replace o'rings and secure cover bolts tightly.
Excess delivery beyond 1%.	1. Vane blades damaged.	Inspect and replace damaged vane blades.
	2. Jammed rotor or calibrating mechanism.	As described above.


## 5 Special Tool

<i>DESCRIPTION</i>	<i>USE</i>	<i>FIGURE</i>
Rotor removal and turning tool  Code 80AT0039	To fit on the rotor spindle in place of rotor gear when turning or removing rotor assembly	 <p style="text-align: right;">A</p>
Cover removal tool (n.2 pieces are necessary)  Code 80AT0042	For extracting front cover.	 <p style="text-align: right;">B</p>
Bearings extractor  Code 80ES0015	For dismounting the internal ring of the bearing after having broken the external ring.	 <p style="text-align: right;">C</p>
Vanes checking tool  Code 80AT0063	For measuring of the vanes length.	 <p style="text-align: right;">D</p>

## 6 Technical data

- Maximum working pressure ..... 1000 kPa
- Working temperature..... -10°C ÷ +50°C
- Maximum flow rate ..... 500 lpm

*The value reproduced in label can change as regards to those shown in the manual*



LE FLANGE DI INGRESSO E DI USCITA POSSONO  
ESSERE RUOTATE DI 90° SUL RETRO  
INLET AND OUTLET FLANGES CAN BE  
TURNED BY 90° TOWARD SIDE BACK



SCARICO DEGASATRICE 1" GAS  
AIR VENT 1" GAS

FLANGE 2" ANSI 150 FF


SPAZIO PER ESTRAZIONE CESTO FILTRO  
CLEARANCE FOR BASKET REMOVAL

- |   |                          |   |                                     |
|---|--------------------------|---|-------------------------------------|
| 1 | CONTATORE                | / | BULKMETER                           |
| 2 | NEFILTER DEGASATORE      | / | COMBINED STRAINER AND AIR SEPARATOR |
| 3 | TESTATA INDICATRICE      | / | COUNTER                             |
| 4 | PREDETERMINATORE         | / | PRESET                              |
| 5 | STAMPATORE               | / | TICKET PRINTER                      |
| 6 | VALVOLA A CHIUSURA LENTA | / | PRESET VALVE                        |
| 7 | VALVOLA CHECK            | / | AIR-CHECK DEVICE                    |

DATA	DISSEGNO	CONTROLLO	REFINAMENTO DISGNO	OPERE DISGNO	NOTE SENZA INDICAZIONE DI TOLERANZA	SCALA	FOGLIO
27-07-93	27-07-93	27-07-93	/	/	/	1:5	NC1 DI 1
				DESCRIZIONE: <b>DISGNO DIMENSIONALE PER PROSPETTO</b> <b>CONTATORI "SBW5"</b>			
Alleanza San'Assessorio (Ferrara) Gruppo Sideraria (Albano) - FAX				DIS. NG <b>4251</b>			
OGNI FORMA DI RIPRODUZIONE DEL PRESENTE DISGNO E VENITA A TERMINE DI LEGGE. PROMOTTA RISERVA GRUPPO ISOIL S.p.A.				INDICE A F B G C H D I E L			



POS.	DENOMINAZIONE	ITEM
1	CONTATORE	P.D.METER
2	FILTRO DEGASATORE	STRAINER AIR SEPARATOR
3	EMETTITORE EM 6422	ENCODER EM 6422
4	VALVOLA CHECK	CHECK VALVE
Tolleranze lineari ISO 2768-m <b>Peso</b> Materiale Trattamento Rugosità		
Tolleranze snussi e raccordi ISO 2768-m / / /		
Tolleranze gradi ISO 2768-m		
Origine disegno /	Descrizione	Emesso FZ/GF Data 11/06/07
Riferimento disegno /	<b>MISURATORE SBM75 AL CF+CHECK</b> <b>SBM75 METER CF+CHECK</b>	Disegnato ZANGHIF Data 11/06/07
Codice /		Controllato FONTANA Data 11/06/07
<b>ISOIL</b> <b>IMPIANTI</b> Albano Sant'Alessandro (Bg) ITALY		Formato originale A3 Scala: 1:5 Foglio: 1 di 1
Disegno n° 5302-3		Indice revisioni A B C D E F G H I L
OGNI FORMA DI RIPRODUZIONE DEL PRESENTE DISEGNO E' VIETATA A TERMINE DI LEGGE PROPRIETA' RISERVATA <b>ISOIL IMPIANTI S.p.A.</b>		






pos.	CODICE	DESCRIZIONE	Q.tà	MATERIALE	pos.	CODICE	DESCRIZIONE	Q.tà	MATERIALE
item	CODE	DESCRIPTION	Q.ty	MATERIAL	item	CODE	DESCRIPTION	Q.ty	MATERIAL
3	-	BM 36/1 BM 36/1	-		18	80COG045	Corpo Body	1	Alluminio Aluminium
6	80SP5009	Spina spirale Spirol pin	1	Acc. carbonio Carbon steel	19	80COB363	Coperchio post. Back cover	1	Acc. carbonio Carbon steel
7*	80GU1582	Guarnizione OR O-Ring	2	Nitrile Nitrile	20*	80COC040	Coppia pattini DX RH Vanes pair	1	-Rilsan -Rilsan
7*	80GU1579	Guarnizione OR O-Ring	2	FKM FKM	22*	80COC070	Coppia pattini SX LH vanes pair	1	-Rilsan -Rilsan
8	80RO1180	Rondella elastica Spring washer	16	Acc. carbonio Carbon steel	24	-	Spessore Shim	1	- -
9	80DA1018	Dado Nut	12	Acc. carbonio Carbon steel	26	80CO0123	Collettore Manifold	1	Alluminio Aluminium
10	80COB123	Coperchio ant. Front cover	1	Alluminio Aluminium	27	80VI2129	Vite Screw	4	Acc. carbonio Carbon steel
11	80AL0323	Alberino Shaft	1	Acc. carbonio Carbon steel					
12	80SP5006	Spina spirale Spirol pin	1	Acc. carbonio Carbon steel					
13*	80CU1102	Cuscinetto Bearing	2	Acc. inox St. steel					
14	80RO2060	Rotore Rotor	1	Alluminio Aluminium					
15	80PR3018	Prigioniero Stud	16	Acc. carbonio Carbon steel					
16*	80GU1135	Guarnizione OR O-Ring	2	FKM FKM					
16*	80GU1138	Guarnizione OR O-Ring	2	Nitrile Nitrile					
17	80SP6018	Spina cilindrica Pin	4	Acc. carbonio Carbon steel					

(\*) Parti di ricambio consigliate  
Suggested spare parts

ASSIEME CONTATORE VOLUMETRICO SBM75  
 ASSEMBLY SBM75 P.D. METER


Dis.6474/1M

REV. A



ISOIL 			ASSIEME CONTATORE SBM 75					Dis. 6474-1M	
I M P I A N T I			SBM75 P.D. METER ASSEMBLY					Foglio 1 di 1	
pos.	N° CODICE	DESCRIZIONE	Q.tà	MATERIALE	pos.	N° CODICE	DESCRIZIONE	Q.tà	MATERIALE
item	N° CODE	DESCRIPTION	Q.ty	MATERIAL	item	N° CODE	DESCRIPTION	Q.ty	MATERIAL
1	80COG009	Corpo collettore Body	1	Alluminio Aluminium	24*	80GU0172	Guarnizione OR O-ring	1	Nitrile Nitrile
2	80COG219	Corpo filtro Strainer body	1	Alluminio Aluminium	24*	80GU0171	Guarnizione OR O-ring	1	FKM FKM
3	80GO1009	Gomito Elbow	1	Alluminio Alluminium	25	80VI4201	Vite Srew	4	Acc. Carbonio Carbon steel
4*	80GU1360	Guarnizione OR O-ring	1	Nitrile Nitrile	26	80RO1207	Rondella elastica Spring washer	4	Acc. Carbonio Carbon steel
4*	80GU1357	Guarnizione OR O-ring	1	FKM FKM	27	80VI2192	Vite Srew	12	Acc. Carbonio Carbon steel
5	80PI1003	Piattello Plate	1	Acc. Carbonio Carbon steel	28	80RO1183	Rondella elastica Spring washer	12	Acc. Carbonio Carbon steel
6	80AL0153	Alberino Shaft	1	Acc. Inox St. steel	29*	80GU1582	Guarnizione OR O-ring	3	Nitrile Nitrile
7	80VI8111	Vite Srew	1	Acc. Carbonio Carbon steel	29*	80GU1579	Guarnizione OR O-ring	3	FKM FKM
8	80SP5009	Spina spirale Spirol spin	1	Acc. al carb. Carbon steel	30	80TA1090	Tappo Pulg	1	Acc. Inox St. steel
9	80AN1018	Anello Ring	1	Alluminio Aluminium	31	80VA4021	Valvola Degasatrice Air vent valve	1	- -
10	80MO0129	Molla Spring	1	Acc. Inox St. steel	32	80VI4267	Vite Srew	4	Acc. Carbonio Carbon steel
11*	80GU1501	Guarnizione OR O-ring	1	Nitrile Nitrile	33	80RO1180	Rondella Washer	4	Acc. Carbonio Carbon steel
11*	80GU1498	Guarnizione OR O-ring	1	FKM FKM	34*	80CE2075	Cesto filtro 100mesh Strain. basket 100mesh	1	Acc. Inox St. steel
12	80BO1039	Boccola O-ring	1	Ottone Brass	34*	80CE2069	Cesto filtro 60 mesh Strain. basket 60mesh	1	Acc. Inox St. steel
15	80VI8051	Vite Srew	4	Acc. Carbonio Carbon steel	34*	80CE2066	Cesto filtro 40 mesh Strain. basket 40 mesh	1	Acc. Inox St. steel
16	80PI1045	Piattello Plate	1	Ottone Brass	35	80GU0024	Guarnizione Gasket	1	Nitrile Nitrile
18*	80GU1195	Guarnizione OR O-ring	1	Nitrile Nitrile					
18*	80GU1192	Guarnizione OR O-ring	1	FKM FKM					
20	80COB297	Coperchio filtro Strainer cover	1	Alluminio Aluminium					
21	80DI0000	Diaframma Diaphragm	1	Acc. al carb. Carbon steel					
22	80CA0006	Calotta Cap	1	Alluminio Aluminium					
23	80PI7012	Pistone Piston	1	Bronzo Bronze	*	Parti di ricambio consigliate / Suggested spare parts			

T-3291+2.XLS



pos. item	N° CODICE N° CODE	DESCRIZIONE DESCRIPTION	Q.tà Q.ty	MATERIALE MATERIAL	pos. item	N° CODICE N° CODE	DESCRIZIONE DESCRIPTION	Q.tà Q.ty	MATERIALE MATERIAL
1	80PI1015	Piattello tenuta Plate	1	Acc. Carbonio Carbon steel	21	80VI8051	Vite Srew	4	Acc. Carbonio Carbon steel
2	80GH0015	Ghiera Metal ring	1	Bronzo Brass	22	80PI1045	Piattello Plate	1	Ottone Brass
3*	80GU0443	Guarnizione Gasket	1	Nitrile Nitrile	23	80SP0162	Vite Srew	1	Ottone Brass
3*	80GU0444	Guarnizione Gasket	1	FKM FKM					
4	80PI7006	Pistone Piston	1	Bronzo Brass					
5	80AN2039	Anello elastico Circlip	1	Acc. Carbonio Carbon steel					
6	80PI1021	Piattello Plate	1	Acc. Carbonio Carbon steel					
7	80PI6000	Pilota Pilot	1	Acc. Inox St. steel					
8	80AN3048	Anello elastico Circlip	1	Acc. Carbonio Carbon steel					
9	80MO0132	Molla Spring	1	Acc. Inox St. steel					
10	80CA1063	Camera valvola Valve chamber	1	Acc. Carbonio Carbon steel					
11	80AG0000	Aggancio di comando Driver	1	Acc. Carbonio Carbon steel					
12	80DA3042	Dado Nut	1	Acc. Carbonio Carbon steel					
13	80LE0027	Leva Lever	1	Acc. Carbonio Carbon steel					
14	80SP5078	Spina Pin	2	Acc. Carbonio Carbon steel					
15*	80GU1195	Guarnizione OR O-ring	2	Nitrile Nitrile					
15*	80GU1192	Guarnizione OR O-ring	2	FKM FKM					
16	80AL0156	Alberino Shaft	1	Acc. Inox St. steel					
17	80DA3015	Dado Nut	1	Acc. Carbonio Carbon steel					
18	80LE0009	Leva Lever	1	Acc. Carbonio Carbon steel					
19	80BO1015	Boccola Bush	1	- -					
20	80PE1003	Perno Shaft	1	Acc. Carbonio Carbon steel	* Parti di ricambio consigliate / Suggested spare parts				

T-3291-2.XLS

N° 4 VITI/SCREWS TCEI M 8x20 COD.80VI4201


N° 4 RONDELLE/WASHERS Ø8 COD. 80R01207

(\* GUARNIZIONE/GASKET VITON COD. 80GU0171

(\* GUARNIZIONE/GASKET TEFLON COD. 80GU0168

(\* PISTONE/PISTON BRONZE COD. 80PI7012

(\* PISTONE/PISTON INOX COD. 80PI7015




ASSIEME VALVOLA DEGASATRICE DIS. 565 GALLEGGIANTE Ø90 { COD. 80VA4021  
VALVE ASSEMBLY FLOAT Ø90


ASSIEME VALVOLA DEGASATRICE DIS. 565 GALLEGGIANTE Ø110 { COD. 80VA4024  
VALVE ASSEMBLY FLOAT Ø110

\* PARTI DI RICAMBIO CONSIGLIATE /SUGGESTED SPARE PARTS







INTRODUZIONE CHIAVI PER  
 TARATURA CONTATORE  
 USE OF KEYS FOR  
 METER'S CALIBRATION



			MECCANISMO DI CALIBRAZIONE SBM 75 MK2 E SBM 75/AL					Dis. 672/75	
I M P I A N T I			CALIBRATION MECHANISM SBM 75 MK2 AND SBM 75/AL					Foglio 1 di 2	
pos.	N° CODICE	DESCRIZIONE	Q.tà	MATERIALE	pos.	N° CODICE	DESCRIZIONE	Q.tà	MATERIALE
item	N° CODE	DESCRIPTION	Q.ty	MATERIAL	item	N° CODE	DESCRIPTION	Q.ty	MATERIAL
1	80SC2009	Scatola meccanismo <i>Calibr.mechanism box</i>	1	Alluminio <i>Aluminium</i>	24	80IN3144	Ingranaggio <i>Gear</i>	1	Acc.al carb. <i>Carbon Steel</i>
2	80VI2042	Vite fissaggio supporto <i>Support screw</i>	4	Acc.al carb. <i>Carbon Steel</i>	26	80RO1075	Rondella di rasamento <i>Shim washer</i>	2	Acc.al carb. <i>Carbon Steel</i>
3	80SV0012	Supporto disp.regolaz. <i>Calibr.mech.support</i>	1	Alluminio <i>Aluminium</i>	27	80BO1009	Boccola autolubrif. <i>Self-lubric. bush</i>	1	Bronzo <i>Bronze</i>
4	80AS0027	Ass.disco frizione <i>Friction wheel</i>	1	Acc.al carb. <i>Carbon Steel</i>	28*	80SP5009	Spina spirale <i>Spirol pin</i>	1	Acc.al carb. <i>Carbon Steel</i>
5		Fornito con pos.4 <i>Supplied with item 4</i>			30	80AL0270	Alberino prolunga <i>Extension shaft</i>	1	Acc.al carb. <i>Carbon Steel</i>
6*	80AS0129	Ass.albero con pign. <i>Shaft with pinion</i>	1	Acc.al carb. <i>Carbon Steel</i>	32	80PI5000	Pignone conico <i>Bevel pinion</i>	1	Acc.al carb. <i>Carbon Steel</i>
7	80AS0258	Ass. vite senza fine <i>Worm screw</i>	1	Acc.al carb. <i>Carbon Steel</i>	33		Viene forn. con pos.17 <i>Supplied with item 17</i>		
8*		Fornito con pos.7 <i>Supplied with item 7</i>	1		34	80AS0084	Ass. alberino/pignone <i>Shaft/gear assembly</i>	1	Acciaio inox <i>St. steel</i>
9*	80CU1081	Cuscinetti <i>Bearings</i>	2	Acciaio inox <i>Stainless steel</i>	35	80IN3162	Ingranaggio <i>Gear</i>	1	Acc.al carb. <i>Carbon Steel</i>
10	80VI4201	Viti <i>Screws</i>	2	Acc.al carb. <i>Carbon Steel</i>	36	80AN2024	Anello elastico <i>Elastic ring</i>	1	Acc.al carb. <i>Carbon Steel</i>
11	80TA1072	Tappo scarico <i>Oil discharge plug</i>	1		37		Fornito con pos.34 <i>Supplied with item 34</i>	1	
12	80TA1015	Tappo carico olio <i>Oil charge plug</i>	1		38	80SP5009	Spina spirale <i>Spirol pin</i>	3	Acc.al carb. <i>Carbon Steel</i>
13	80VI5117	Vite <i>Screw</i>	1	Acc.al carb. <i>Carbon Steel</i>	39	80IN0006	Indicatore livello olio <i>Oil level indicator</i>	1	
14	80COB069	Coperchio accesso <i>Calibrating cap</i>	1	Alluminio <i>Aluminium</i>	40	80MA1012	Manicotto per trasmis. <i>Transmission sleeve</i>	1	Acc.al carb. <i>Carbon Steel</i>
15	80AN2018	Anello elastico <i>Bearing circlip stop</i>	1	Acc.al carb. <i>Carbon Steel</i>	41		Fornito con pos.6 <i>Supplied with item 6</i>	1	
16	80RO1063	Rondella rasamento <i>Shim washer</i>	7	Acc.al carb. <i>Carbon Steel</i>	42	80SP5006	Spina spirale <i>Spirol pin</i>	1	Acc.al carb. <i>Carbon Steel</i>
17	80AS0123	Assieme ingranaggi <i>Gears assembly</i>	1	Acc.al carb. <i>Carbon Steel</i>	43	80RO1078	Rondella di rasamento <i>Shim washer</i>	2	Acc.al carb. <i>Carbon Steel</i>
18	80AL0132	Alberino <i>Gear pin</i>	1	Acc.al carb. <i>Carbon Steel</i>	44*	80GU1243	Guarnizione <i>Gasket</i>	1	Viton <i>Viton</i>
19	80MO0228	Molla spingi disco friz. <i>Friction plate spring</i>	1	Acciaio inox <i>St. steel</i>	45	80AN2006	Anello elastico <i>Circlip</i>	1	Acc.al carb. <i>Carbon Steel</i>
20	80PI1057	Piattello per frizione <i>Friction plate</i>	1	Acc.al carb. <i>Carbon Steel</i>	46		Fornito con pos.17 <i>Supplied with item 17</i>		
21	80RO1042	Rondella di centraggio <i>Centering washer</i>	1	Acc.al carb. <i>Carbon Steel</i>	47	80BO1000	Boccola <i>Bush</i>	2	Bronzo <i>Bronze</i>
22*	80CU1045	Cuscinetto reggispinta <i>Axial bearing</i>	1	Acc.al carb. <i>Carbon Steel</i>	48		Fornito con pos.17 <i>Supplied with item 17</i>		
23	80BO1000	Boccola <i>Bush</i>	2	Bronzo <i>Bronze</i>	* Parti di ricambio consigliate / Suggested spare parts				







T-3958.DOC

ISOIL 		SCATOLA DI TRASMISSIONE PER MONT.TESTATA VEGA					Dis. 3958		
I M P I A N T I		GEARING BOX FOR ELECTR. COUNTER VEGA MOUNTING					Foglio 1 di 1		
pos.	N° CODICE	DESCRIZIONE	Q.tà	MATERIALE	pos.	N° CODICE	DESCRIZIONE	Q.tà	MATERIALE
item	N° CODE	DESCRIPTION	Q.ty	MATERIAL	item	N° CODE	DESCRIPTION	Q.ty	MATERIAL
1	80SC2030	Scatola meccanismo <i>Mechanism box</i>	1	Alluminio <i>Aluminium</i>	24	80IN3276	Ingranaggio <i>Gear</i>	1	Acc.carbonio <i>Carbon steel</i>
2	80MA1009	Manicotto di trasmissione <i>Transmission coupling</i>	1	Acc.carbonio <i>Carbon steel</i>	25	80SP5009	Spina spirale <i>Spiral pin</i>	1	Acc.carbonio <i>Carbon steel</i>
3	80SP5018	Spina spirale <i>Spiral pin</i>	1	Acc.carbonio <i>Carbon steel</i>	26	80AS0102	Trascinatore <i>Entrainer</i>	1	Acc.carbonio <i>Carbon steel</i>
4	80RO1078	Rondella di rasamento <i>Washer</i>	4	Acc.carbonio <i>Carbon steel</i>					
5	80IN0006	Indicatore livello olio <i>Oil level indicator</i>	1						
6	80SU0072	Supporto mecc.perVEGA <i>Mech.support for</i>	1	Alluminio <i>Aluminium</i>					
7	80BO1147	Boccola <i>Bush</i>	1	Bronzo <i>Bronze</i>					
8	80AL0243	Alberino <i>Shaft</i>	1	Acc.inox <i>St. steel</i>					
9	80GR1093	Grano <i>Grain</i>	1	Acc.inox <i>St. steel</i>					
10	80AN2006	Anello elastico <i>Retaining ring</i>	2	Acc. al carb. <i>Carbon steel</i>					
11	80AL0246	Alberino <i>Shaft</i>	1	Acc. inox <i>St. steel</i>					
12	80AN2000	Anello elastico <i>Retaining ring</i>	1	Acc. al carb. <i>Carbon steel</i>					
13	80TA1072	Tappo scarico olio+guarn. <i>Oil discharge plug</i>	1						
14	80BO1099	Boccola <i>Bush</i>	1	Bronzo <i>Bronze</i>					
15	80RO1066	Rondella di rasamento <i>Washer</i>	2	Acc. al carb. <i>Carbon steel</i>					
16	80VI2042	Vite <i>Screw</i>	4	Acc. al carb. <i>Carbon steel</i>					
17	80RO1033	Rondella dent.esterna <i>External washer</i>	4	Acc. al carb. <i>Carbon steel</i>					
18	80TA1015	Tappo carico olio <i>Oil charge plug</i>	1						
19	80GU0207	Guarnizione <i>Gasket</i>	1						
20	80VI5117	Vite <i>Screw</i>	1	Acc. al carb. <i>Carbon steel</i>					
21	80COB069	Coperchio accesso tar. <i>Calibr.inlet cover</i>	1	Alluminio <i>Aluminium</i>					
22	80VI8048	Vite <i>Screw</i>	2	Acc. al carb. <i>Carbon steel</i>					
23	80IN3279	Ingranaggio <i>Gear</i>	1	Acc. al carb. <i>Carbon steel</i>					