

A compressors

Minimize Heat Losses

Place the compressor next to the vessel to be emptied.

Long discharge lines = Heat loss
 = Premature condensation
 = Slow transfer rate

